

WALL CLOCKS

Please read before installing your new clock.

Quick setup, troubleshooting and hanging instructions.

1-IMPORTANT — CHECK YOUR CLOCK HANDS


Due to vibration during shipping, the hands may shift or fall off track.

Clock hands must NOT touch each other for the clock to keep accurate time. There must be a 2 mm / 1/8" gap between the two hands (see diagram).


If the hands moved during shipping, see the Troubleshooting section on page 2.

If a hand is bent and cannot be straightened, please contact us — we will quickly send a replacement.

Please follow the second step in the back.



2- BATTERY




1. Insert battery into the back of the clock, paying attention to + / – direction.
2. Turn the knob counter-clockwise to set time.
3. Replace the battery when power runs out.

Use only standard Alkaline batteries. Do NOT use rechargeable or extra-power batteries (e.g. Duracell Extra Power).

3- TROUBLESHOOTING


1. Slowly remove the small pin / screw holding the hands.
2. Remove the top (longest) hand fully.
3. Push the small hand down until it clicks into place.
4. Repeat for the longer hand — it must also click into place.
5. Replace the pin to secure both hands. Rotate twice counter-clockwise; set the time.



HANGING INSTRUCTIONS



1. Choose a wall location for your clock. The hanging bracket is built into the wood frame.
2. The top of each frame has a lip that hangs over the included screws (use 2–4 screws depending on size).
3. Set the time by manually moving the hands, then insert the battery in the back. The clock will start ticking once the battery is installed.



FOR YOUR CONVENIENCE

An extra securing pin is included in a small bag attached to the back of your clock.

WARNING / DISCLAIMER

Metal artwork has sharp edges and corners that can cause injury. If hung over a bed, sofa or seating area, leave at least 8 inches between the artwork and any furniture or person. Household temperature, humidity or mishandling may affect adhesives over time. We will replace defective items, but use of this metal artwork is at your sole risk; all other warranties are expressly disclaimed.