




120Mins



x2






CUSTOMER FIRST, SERVICE FOREMOST!


Questions? Issues?







CONTACT US








REPLY WITHIN 24 HOURS ON WEEKDAYS


















Label	Part Image	Description	Qty
A		Dowel	14
B		314*15 Iron Rod	3
C		4*35 Flat Head Self-tapping Screw	10
D		Three-in-one Screwok	34
E		4*50 Flat Head Self-tapping Screw	11
F		Three-in-one screw Disk	34
G		Pull Ring	6
H		Strike Plate	4
J		Magnetic Touch	2
K		Slide Rail	4
L			4
M		314*25 Iron Rod	1
N		Plastic Shaft Pin	4
P		5*16 Iron Boltn	4





Label	Part Imag	Description	Qty
Q		1/4*50 Screw	10
R		Cross Dowels Slotted Nuts	8
S		1/4*12 Screw	50
Y		Casters without Brake	3
U		Casters with Brake	2
V		Plastic Furniture Corner Brace	9
W		Folding Shelf Bracket	3
T		3.5*14 Flat Head Screw	12
Z		M4X12mm	4
		Screwdr iver	1

Label	Part Image	Description	Qty
①		Back Counter Top	1
②		Back Board	2
③		Middle Back Connection Board	1
④		Right Back Connection Board	1
⑤		Left Back Connection Board	1
⑥		Side Board of Right Shelf	2
⑦		Right Side Board	1
⑧		Bottom Board	1
⑨		Upper Fixing Board	2

Label	Part Image	Description	Qty
⑩		Lower Fixing Board	2
⑪		Middle Vertical Board	1
⑫		Left Side Board	1
⑬		Left Side Board of Left Shelf	1
⑭		Middle Board of Left Shelf	1
⑮		Right Side Board of Left Shelf	1
⑯		Counter Top	1
⑰		Back Board of Drawer	2
⑱		Left Side Board of Drawer	2





Label	Part Image	Description	Qty
19		Front Board of Drawer	2
20		Bottom Board of Drawer	2
21		Right Side Board of Drawer	2
22		Left Door Board	2
23		Right Door Board	2























Tips:









The spice rack could be installed in 2 different ways as shown in the picture 1 and picture 2. You could choose as you prefer.


























































































X2




I pull out the rail from the cabinet frame




II slot in drawer










III align the hole circled in Figure IV with the hole of the drawer and screw the G to holes from the inside of the drawer




IV ✓





X2

Note:Put the P part to the hole first and then put the N part



CARE AND MAINTENANCE

- Before using, clean the product completely with soft, dry towel. When not in use, wipe free of any dirt or loose objects, wash with a mild solution of soap and water; rinse thoroughly and dry completely.
- Do not use strong detergent or abrasive cleaners on wood surface finish.
- Moisture and heat can damage any wood finish. Protect your furniture by using coasters and trivets. Always wipe up spilled liquid promptly and dry with a soft cloth.
- Avoid dragging sharp or rough objects across the surface of your wood furniture. Use coasters or placemats to help prevent scratches on the wood surface.
- Wood will expand and contract with seasonal humidity changes. Maintain consistent humidity levels to minimize movement in the wood and prevent warping.
- Over time, strong sunlight will change the color of the furniture. Do have curtain or window shades to block out direct strong sunlight.
- Dust regularly
- Clean with damp cloth whenever necessary.
- Periodically check and ensure that all bolts are well-tighten during use