





Please check that all fittings are available and in good condition before assembly.
If you have any questions, please contact us , we will solve your problem in the first time.

PARTS LIST


Ax5 	Ix1(R&L) 
Bx1 	Jx13  M6x18mm
Cx5 	Kx6  M6x22mm
Dx1 	Lx4  M6x30mm
Ex1 	Mx2  5mm
Fx1 	Nx1 
Gx1 	
Hx1 	

ASSEMBLE INSTRUCTION


1




2



3




4



The long side of the steel plate shall face upward.

5



6

