


SICOTAS

ND130A1XBNY1700 | ND130A2XLTY1702 | ND130A2XBNY1703



Zura Collections

Assembly Instructions

Before beginning the assembly process, please read and save these instructions for reference. Following these guidelines will ensure a smooth and successful assembly of your product.

1. Part Identification:

Carefully separate and identify all the parts included in your package. Confirm that you have all the components listed in the instruction manual. This step will help you avoid any missing or misplaced parts during assembly.

2. Work Surface:

To prevent any scratches or damage to the product, assemble it on a soft mat or a similar protective surface. This will provide a cushioned area for the components and protect the surfaces from unwanted marks.

3. Step-by-Step Assembly:

Follow the assembly instructions provided, proceeding one step at a time. Take care to understand each step properly before proceeding to the next one. This sequential approach ensures that the assembly is done correctly and minimizes the chance of errors.

4. Proper Screw Seating:

When attaching screws and nuts, it is essential not to fully tighten them until all screws are correctly seated. By partially tightening each screw and nut initially, you can ensure that they are aligned properly and fit securely before final tightening.

5. Avoid Over-Tightening:

While each screw and nut should be tightened correctly, it is crucial not to over-tighten them. Over-tightening can cause damage to the product or compromise its structural integrity. Use the appropriate amount of force to secure the components without excessive tightening.

SICOTAS customer help center:

If you encounter any questions or problems during the assembly process, please do not hesitate to contact us.

We strive to provide excellent customer support and will respond to your inquiries within 24 hours. Our team will offer you a suitable solution to address any concerns you may have.



Email:
service@sicotas.com



Website:
www.sicotas.com



Phone:
(833) 742-6827



Official Website:



WhatsApp:



YouTube:



Instagram:




Facebook:




TikTok:

Parts List




Hardware List




Code	Description	Quantity
A	ø15x9.5mm Cam lock	36+2
B	M6*24mm Cam bolt	36+2
C	ø8x30mm Wood dowel	16+2
D	ø4x13 screw	12+2
E	Foot pad	4+1
F	Rebound device	3
G	ø6x30mm Wood dowel	6+2
H	ø3x16 screw	10+2
I	ø3.5x12 screw	36+2
J	Backboard clip	10+2

Code	Description	Quantity
K	ø3x13 screw	3
L	ø4x30 screw	18+2
M	4mm Hex key	1
N	ø7x48mm Screw	4+1
O	Drawer runner set	3


Step 1




Step 2




Step 3




Step 4




Step 7





Step 8




Step 9




Step 10




Step 11




Step 12



Step 13







Must Be Installed



J * 10	H * 10


Step 14



B * 18	k * 3


X3

Step 15




X3

Step 16




X3

Step 17




X3


Step 18





Note: You can adjust the knob of the bouncer to control the bouncing effect.



Please note that the drawers must be installed as indicated by the arrows.



Step 19



Operating Instruction: To open or close the drawer, press the area near the drawer front panel that has a rebound device.

Step 20

