

DINING CHAIR

ASSEMBLY INSTRUCTIONS



Assembly Instruction

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !

1. Don't attempt to repair or modify parts that are broken or defective .Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.


PARTS IDENTIFICATION

A CUSHION



1PC

B FRONT LEG








2PCS

C BACK LEG




2PCS


z HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q' TY
1	Ø LOCK WASHER 5/16"		8PCS
2	Ø FLAT WASHER 5/16"		8PCS
3	Ø BOLT 5/16"X2"		4PCS
4	Ø BOLT 5/16"X2-1/2"		4PCS
5	Ø ALLEN KEY 5/16"		1PC

STEP:1



STEP:2



STEP:3

