














User's Manual












PRODUCT PARTS:


A	B	C	D	E	F
					
1PC	1PC	1PC	2 PCS	1PC	1PC
G	H	I	J	K	L
					
1PC	1PC	1PC	1PC	1PC	1PC
M					
					
1PC					

HARDWARE:


①	②	③	④	⑤	⑥
					
1/4"x25mm	20x20x33mm	Ø3x12mm	Ø4x25mm	Ø8x30mm	
14+1 PCS	2 PCS	8 PCS	4 PCS	18+1 PCS	2 PCS
⑦	⑧	⑨	⑩	⑪	⑫
					
Ø4x12mm	12"x45mm	Ø3x10mm	Ø6x33mm	Ø15x9mm	
12+1 PCS	1 SET	12+1 PCS	10+1 PCS	10+1 PCS	2 PCS
⑬					
					
5/32"x15mm					
2 PCS					


STEP 1

- | | | |
|---|--|--|
|  20x20x33mm 2pcs |  Ø3x12mm 4pcs |  Ø8x30mm 2pcs |
|---|--|--|




STEP 2

- | |
|--|
|  Ø8x30mm 8pcs |
|--|





STEP 3

⑤  4pcs
Ø8x30mm




STEP 4

⑤  4pcs
Ø8x30mm



STEP 5


- ⑧  1SET
12"x45mm




STEP 6


- 8a  12"x45mm

- ⑨  3pcs
Ø3x10mm



- ⑩  3pcs
Ø6x33mm



STEP 7



STEP 8




STEP 9

- | | | |
|--|--|---|
| 1


1/4"x25mm
7pcs | 3

Ø3x12mm
2pcs | 11


Ø15x9mm
3pcs |
|--|--|---|



STEP 10


- | | |
|--|--|
| 8b

12"x45mm | 9

Ø3x10mm
6pcs |
|--|--|




STEP 11

- ④  4pcs
Ø4x25mm




STEP 12





STEP 13

- ⑩  4pcs
Ø6x33mm







STEP 14




- ⑪  4pcs
Ø15x9mm
- ⑫  1pc
- ⑬  1pc
5/32"x15mm



STEP 15



STEP 16





STEP 17

7  8pcs
Ø4x12mm


Three-way adjustable hinge for perfectly aligned doors

1. TO ADJUST DOOR FORWARD OR BACKWARD.
2. TO ADJUST DOOR TO RIGHT OR TO LEFT.
3. TO ADJUST DOOR UP OR DOWN.




STEP 18


12  1pc
13  1pc
5/32"x15mm



STEP 19



STEP 20



IMPORTANT-READ CAREFULLY-RETAIN FOR FUTURE REFERENCE

WARNING:

- Children must stay away from the assembly zone, preventing children from potential asphyxia because of plastic bag and foam breathing in nose;
- For your safety, please do not tread or climb product.
- The loading weight shall be within the range that vendor claims. The product is designed for adults use, domestic use and indoor use only.
- The product shall not combine with other product for use.
- If the product with seat height adjustments with energy accumulators that only trained personnel may replace or repair seat height adjustment components with energy accumulators
- Check regularly that all assembly fastenings are properly tightened, do not use the product if any structural part is broken or missing
- Incorrect installation and incorrect use can cause accidents. Please completely follow the guidance of assembly instruction.

Security instructions:

- Before assembling check whether all parts listed in the parts list have been delivered. Do not start assembling if parts are missing or damaged.
- A failure to assemble this product correctly could cause damage or result in serious injury! Before assembling make sure that you have enough space for the procedure. Assemble on a flat surface.
- Keep the assembly instructions available at all times and follow each of the individual steps exactly.
- During assembly, be careful with all the parts of the assembly (do not walk on them or distort them) and beware of shearing and trapping risks. Keep children and pets away while setting up the furniture.