Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.


NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

PART LIST				
ITEM	DESCRIPTION	BOX	QTY	
A	HEADBOARD	1	1 PC	
В	HEADBOARD PANEL	1	2 PCS	
С	FOOTBOARD	2	1 PC	
D	SIDE RAIL	2	2 PCS	
E	CENTER RAIL	2	1 PC	
F	CENTER SUPPORT LEG	2	3 PCS	
G	BED SLAT	3	1 SET	
H	BED LEG	2	2 PCS	

HARDWARE LIST (BOX : 2)				
ITEM	DESCRIPTION		QTY	
1	JCBC BOLT M6 x 20mm	((((((((((((((((((((((((((((((((((((16 PCS	
2	JCBC BOLT M6 x 35mm	 ⊙	1 PC	
3	JCBC BOLT M6 x 45mm	@	3 PCS	
4	M6 FLAT WASHER	0	19 PCS	
5	M6 SPRING WASHER	0	19 PCS	
6	M8 FLAT WASHER	0	2 PCS	
7	M8 SPRING WASHER	0	2 PCS	
8	5/16 HEX NUT		2 PCS	
9	LB 001 CONNER BRACKET		2 PCS	
10	VMB 3172	Ğ	2 PCS	
11	SPANNER 13mm	<u></u>	1 PC	
12	WOOD SCREW M4 X 20mm	••••••••••••••••••••••••••••••••••••••	1 PC	
13	WOOD SCREW M4 X 38mm	400000	14 PCS	
14	M4 ALLEN KEY (BALL SHAPE)	Γ	1 PC	
15	M5 ALLEN KEY (BALL SHAPE)	ſ	1 PC	





Take out HEADBOARD PANEL (B) & VMB3172 (10) for the HEADBOARD BACK (A).

