

HIGH ROCKING CHAIR

Read all assembly and care instructions carefully before using this product. Save these instructions for future reference.

- Select a smooth, level surface to place the Rocking Chair.
- Assemble components on a soft, clean surface to avoid scratching and/or damaging the finish.
- Ensure all parts are accounted for before disposing of packaging.

I WARRANTY INFORMATION

Thank you for choosing Tranquillo. We stand behind our brand and the quality of the items we sell. Tranquillo is not responsible for normal wear and tear, for products used commercially or for failures caused by accidents, abuse, alteration, modification, misuse or improper care.
There are no other express warranties beyond the terms of this limited warranty. In no event shall any implied warranties, including merchantability and fitness for a particular purpose, extend beyond the duration of the express warranty contained herein. In no event shall Tranquillo be liable for incidental or consequential damages.
We offer these warranties:

- **01-year warranty for the chair**

Replacement parts or products will be sent at our discretion if the defect is the result of any fault on our side. Proof of purchase, with the date of purchase as well as photos of the defective merchandise, must be provided. Photos are used to determine the cause of defects and for future quality control.

I IMPORTANT INFORMATION

Under normal use, Tranquillo Rocking Chair will last for years.
It is, however, important to follow basic care tips to prolong the life of your chair.

USE & CARE

- Before each use, inspect the rocking chair for cracks, loose screws, or signs of wear.
- Sit gently and avoid sudden or aggressive rocking movements to prevent tipping or instability.
- Ensure all parts are properly assembled and securely tightened before use.
- Supervise children when using the rocking chair to avoid accidents.
- Pets should not be allowed on the chair to prevent scratches or structural damage.
- Do not exceed the recommended weight capacity of the chair.
- Store the rocking chair in a dry, sheltered area when not in use. Extended exposure to rain or moisture may affect the wood's longevity.
- Clean the wooden surface with a soft cloth and warm water. Dry thoroughly after cleaning to prevent moisture buildup.
- The wood finish is durable but may develop minor scratches over time. Wipe scratched areas as needed and consider applying a protective wood sealant annually for outdoor durability.

TROUBLESHOOTING


If the chair seems unstable, make sure it is on a level surface and the feet are correctly distributed as shown in the assembly instructions. Also make sure that all components are assembled correctly and the hardware is securely tightened.

Any modification or failure to follow the recommended care will void the product warranty.


⚠ WARNING

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.


COMPONENTS:




1 LEFT SIDE × 1PC




2 RIGHT SIDE ×1PC




3 LEFT SIDE ARM SUPPORT ×1PC




4 ROCKERS × 2PCS



5 BACK ×1PC



6 SEAT ×1PC




7 FRONT RAIL ×1PC



Phillips head screwdriver required for assembly, not included in fitting pack.


A  7×70×15 LARGE SCREW 14PCS

B  4×30 SMALL SCREW 2PCS


C  HEX WRENCH 1PC

PRODUCT ASSEMBLY


STEP 1: Connect rockers.




STEP 2: Connect left side arm support.




STEP 3: Connect backrest and front rail to left side.



STEP 4: Connect seat to left side.



STEP 5: Connect right side to back rest and front rail.



STEP 6: Connect right side to seat.

