








## CUSTOMER SERVICE

All the legs and screws of the dining chair are placed at the bottom of the chair. Opening the cover and you will see them.

If you are missing parts or have any questions about this product, contact our customer service representative first!

| HARDWARE LIST | CODE | PARTS       | QTY. |
|---------------|------|-------------|------|
|               | 1    | BACK        | 1    |
|               | 2    | SEAT        | 1    |
|               | 3    | BACK LEG B  | 2    |
|               | 4    | FRONT LEG F | 2    |

| HARDWARE LIST | CODE | PARTS                                                                                                                                                                       | QTY. |
|---------------|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
|               | A    | M8x55MM   | 9    |
|               | B    | M8x60MM   | 4    |
|               | C    | ALLEN KEY                                                                                  | 1    |



A few days after initial assembly, the product may acclimate to its new environment. Please ensure all screws are still securely tightened.