

Care & Instructions

Thank you for purchasing our.

This is designed to provide pets with adjustable 86~149°F even and constant temperature. It's ideal for all pets in cold winter looking for warm spot to nap, aging pets or those with arthritis or rheumatism, feral cats and kittens etc. It is truly the perfect companion for your pet during the cold winter. This is designed for use with animals only.

WARNING: This is an electrical product. Read all directions and precautions carefully before use. Failure to follow all instructions may cause electrical shock or fire which could cause serious bodily injury.

Important Safeguards

When using electrical appliances should always follow basic safety precautions, including the following:

1. Read all instructions before use.
2. To protect against electrical hazards, DO NOT immerse cord, plug, or appliance in water or other liquid.
3. Not for use on humans.
4. Use only with the supplied supplemental cover
5. Do not wash this heat mat.
6. Do not machine wash. Spot clean by hand only.
7. Discard this pad if it shows any signs of deterioration to the pad or its cord.
8. Closely supervise children near the heated mat.
9. Unplug when not in use!
10. Do not puncture pad for any reason.
11. For use with provided power supply only, do not modify electric connection in any way.

Specification Chart

Rating	Dimension
110-120V 40W	15.7"*15.7"
MADE IN CHINA	

Warranty

1. One Year Limited Warranty
2. Should you have any questions during the use of our

INSTRUCTIONS

1. Make sure the power cord is properly handled if you install this pet heating pad in a cat house.
2. Make sure the cover that comes with the heating pad is on the heating pad before using it with your pets. Do not let pets touch the heating pad directly without the cover.
3. Carefully check the condition of the heating pad for any signs of damage before you plug it in.
4. Plug it into a 110-120 volt AC outlet. For fast heating, you can set the temperature to the highest level (65°C/149°F) at first 1 hour. Sometimes the pad will feel slightly warmer than the ambient temperature, but when the pet lies on it, heat cannot escape. It will reach and maintain the set temperature evenly and constantly.
5. Unplug it when not in use, clean it with a damp cloth, and store it properly.

Controller Use Guide:

*ON/OFF: Press  power key to turn on or turn off the controller.

*Fast-Heating Mode: Press and hold the temperature setting key  for 2 seconds to fast-heating mode. The panel temperature will jump to 149°F for 1 hour. Tap the temperature setting  key to exit the fast-heating mode and return to the default mode.

*HEAT: Press  key Temp LED start to blink then press up  or down  key to set temperature depending on our need and using conditions. Default temperature is 45°C/113°F. 6 Heat Levels for customers' options: 30°C/86°F, 35°C/95°F, 40°C/104°F, 45°C/113°F, 50°C/122°F, 55°C/131°F.

*TIMER: Press  key the timer LED start to blink then press up  or down  key to set timer depending on our need, pad will auto shut off after timer runs out except we set it at the ON (always on) level. Default timer level is 8H.

6 Timer Levels for customers options: 2H, 4H, 8H, 12H, 24H and ON H (Always on).

