





Three-piece glider set




Instruction Manual



Parts List

Grant Park Oversized Tête-à-Tête

No.	Illustration	Description	Qty.	No.	Illustration	Description	Qty.
A		Left Arm	2	I		Chair Seat & Back	2
B		Right Arm	2	J		Left Leg Tube	2
C		Back Cross Bar	2	K		Right Leg Tube	2
D		Swan Bar	4	L		Chair Cross Bar	4
E		Front Support Bar (for Glass Tabletop)	1	M		M6 x 15mm Bolt	12
F		Back Support Bar (for Glass Tabletop)	1	N		M6 x 35mm Bolt	4
G		Table Cross Bar	1	O		M6 x 45mm Bolt	12
H		Glass Tabletop	1	P		M6 x 50mm Bolt	8

Q		M6 x 60mm Bolt	16	U		8mm Plastic Spacer	8
R		M6 Nut	32	V		14mm Plastic Spacer	4
S		Steel Washer	48	W		Allen Wrench	2
T		5mm Plastic Spacer	8	X		Open Wrench	2

Assembly Instructions

Grant Park Oversized Tête-à-Tête

Important:

- Read all the instructions before assembly. Failure to do so may result in faulty assembly and potential injury.
- Before beginning to assemble the product, remove all protective materials, hardware kit(s), and identify all parts packed in the carton are present. (Note: If any part is missing or damaged, do not attempt to assemble). Contact InSide Out Customer Support Team. See page 8.
- Two people are required to assemble heavy items.
- Assemble product on a soft and non-abrasive surface, such as carpet to avoid damaging the item.

DO NOT TIGHTEN BOLTS UNTIL ALL PARTS ARE ASSEMBLED (STEP 8)

Step 1: Attach the Back Cross Bar (C) to the Right Leg Tube (K) and Left Leg Tube (J) using Bolts (M) and Washers (S). Attach the Swan Bars (D) to the Left Leg Tube (J) and Right Leg Tube (K) using Bolts (O), Plastic Spacers (T), Washers (S) and Nuts (R). See Figure 1. Repeat for Chair #2.




Figure 1

Step 2: Attach the Chair Cross Bars (L) to the Right Leg Tube (K) for Chair #1 and to the Left Leg Tube (J) for Chair #2 using Bolts (Q), Washers (S) and Nuts (R). Do not attach opposite end of the Chair Cross Bars (L) until Step 6. See Figure 2 and Figure 3.

Step 3: Attach the Right Arm (B) and Left Arm (A) to each Swan Bar (D) using Bolts (P), Plastic Spacers (U), Washers (S) and Nuts (R). Repeat for Chair #2. See Figure 2 and Figure 3.




Figure 2 (Chair #1)




Figure 3 (Chair #2)

Step 4: Attach the Back Support Bar (F) and Front Support Bar (E) to the bottom of the Glass Tabletop (H) using Bolts (M). See Figure 4.




Figure 4

Step 5: Attach the Table Cross Bar (G) to the Front Support Bar (E) and Back Support Bar (F) using Bolts (N) and Washers (S). See Figure 5.




Figure 5

Step 6: Attach the Glass Tabletop to each chair by inserting the Table Cross Bars (G) into the Chair Cross Bars (L) and secure to the front and back of Leg Tubes (K and J) using Bolts (Q), Washers (S) and Nuts (R) See Figure 6.




Figure 6

Step 7: Attach each Chair Back (I) to the Left Arm (A) and Right Arm (B) using Bolts (O), Washers (S), and Plastic Spacers (V). See Figure 7-1. Attach each Chair Seat (I) to the Left Arm (A) and Right Arm (B) using Bolts (Q), Washers (S) and Nuts (R). See Figure 7-2.




Figure 7-2

Step 8: Check alignment and make adjustments if necessary. **Tighten all Nuts and Bolts.**

Maintenance & Care

Maintenance is required for all outdoor furniture and accessories. Inspect all hardware thoroughly before use and during the season to make sure bolts are securely fastened. Use furniture covers or store out of the elements when not in use. Failure to maintain the furniture will void warranty.

- Frame:** Clean frames with a mild soap and warm water. Do not use abrasive materials, cleaners or bleach. Rinse with clean water and dry thoroughly.
- Tabletop:** Clean the tabletop with a soft cloth or sponge. Never use scouring creams, abrasive cleaners, acid or petroleum-based products. Wash with warm water and dry thoroughly.
- Fabric:** Fabric may be cleaned by hand with a mild solution of soap and water. Rinse fabric thoroughly and allow it to drip dry. Do not use bleach or solvents on fabrics.
- Wicker:** Clean the resin wicker with a soft cloth or sponge. Never use scouring creams, abrasive cleaners, acid or petroleum-based products. Wash with warm water and dry thoroughly.