



ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Screwdriver
(Not included)



(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts?
We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




Save the instructions and store
any supplied tools for later
maintenance.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DINING TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1



Table top
1pc

2



Pedestal
3pcs

3



Top Ring
1pc


4



Base Ring
1pc


HARDWARE

A




Bolt 1/4"×1-1/8"
12 PCS

B



Bolt 1/4"×1-3/4"
3 PCS

C



Bolt 1/4"×3/4"
3 PCS

D



Spring Washer 1/4"
15 PCS

E




Washer 1/4" (Ø16mm)
3PCS

F







Washer 1/4" (Ø13mm)
12 PCS

G




Allen wrench
1PC

Carton	Designation	Part		Hardware
	Table top 1pc	1		A 12 PCS  B 3 PCS 
	Pedestal 3pcs	2		C 3 PCS  D 15 PCS 
	Top Ring 1pc	3		E 3 PCS  F 12 PCS 
	Base Ring 1pc	4		G 1 PC 

ASSEMBLY INSTRUCTIONS

1


Part 2 x 3pcs
Hardware Ax3pcs
Hardware Dx3pcs
Hardware Fx3pcs
Hardware Gx1pc



In this step, tighten the screws to 80%.
Note: Do not lock the screws.

2


Part 3 x 1pc
Hardware Ax6pcs
Hardware Dx6pcs
Hardware Fx6pcs
Hardware Gx1pc



In this step, tighten the screws to 80%.
Note: Do not lock the screws.

3


Hardware Ax3pcs
Hardware Dx3pcs
Hardware Fx3pcs
Hardware Gx1pc



ASSEMBLY INSTRUCTIONS

4


Part 4x 1pc
Hardware Bx3pcs
Hardware Gx3pcs



In this step, tighten the screws to 80%.
Note: Do not lock the screws.


5

Part 1x 1pc
Hardware Cx3pcs
Hardware Dx3pcs
Hardware Ex3pcs
Hardware Gx1pc




In this step, tighten the screws to 80%.
Note: Do not lock the screws.

6



Note: Fully tighten all bolts at this step.

7



Adjust Pre-installed Levelers
height to achieve balance.

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.




Keep this handy!
Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!
To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.


ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Screwdriver
(Not included)



Allen Wrench



2 - People

ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts?
We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**




Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




Save the instructions and store
any supplied tools for later
maintenance.


After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DINING CHAIR




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1




Seat
1pc

2



Back leg
1pc


3



Front leg
1pc


HARDWARE

A



Bolt 1/4"*2-1/8"
2 PCS

B



Bolt 1/4"*1-5/8"
4 PCS

C




Spring Washer 1/4"
6 PCS

D








Washer 1/4"
6 PCS

E




Allen wrench
1PC

Carton	Designation	Part		Hardware
	Seat 1pc	1		A 2 PCS  B 4 PCS  C 6 PCS 
	Back leg 1pc	2		D 6 PCS  E 1 PC 
	Front leg 1pc	3		

ASSEMBLY INSTRUCTIONS

1


Part 2 x 1pc
Part 3 x 1pc
Hardware Ax2pcs
Hardware Cx2pcs
Hardware Dx2pcs
Hardware Ex1pc



Note: Do not fully tighten the bolts at this step.


2

Part 1 x 1pc
Hardware Bx4pcs
Hardware Cx4pcs
Hardware Dx4pcs
Hardware Ex1pc



Note: Do not fully tighten the bolts at this step.


3



Tighten the screws in the circle first, and then tighten the remaining screws.

ASSEMBLY INSTRUCTIONS

4



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.