


ASSEMBLY INSTRUCTION

ITEM NO.N715P296581

Dining Table



IMPORTANT NOTE:

- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCATCHED.**
- 2 BEFORE YOU BEGIN,KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.**
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP.**

ASSEMBLY INSTRUCTION

ITEM NO.N715P296581

Please read these instructions fully before starting assembly:




1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.





ASSEMBLY INSTRUCTION

ITEM NO.N715P296581



ASSEMBLY INSTRUCTION



ITEM NO.N715P296581

Part List	Hardware List
A 	1  Ø 5/16" x 55 mm BOLT (8 pcs)
	2  Ø5/16" x 13 mm LOCK WASHER (8 pcs)
	3  Ø5/16" x 19 x 2 mm FLAT WASHER (8 pcs)
	4  4 mm ALLEN KEY (1 pc)
B  TABLE TOP (1 pc)	TABLE LEG (4 pcs)

ASSEMBLY INSTRUCTION

ITEM NO.N715P296581

STEP 1:



x4

BOLT Ø 5/16 " x 55mm	LOCK WASHER Ø 5/16 " x 13mm	FLAT WASHER Ø 5/16 " x 19x2mm	ALLEN KEY 4 mm
			
1 x 8	2 x 8	3 x 8	1 x 1

ASSEMBLY INSTRUCTION

ITEM NO.N715P296581

COMPLETE

