

# ASSEMBLY INSTRUCTIONS



## *Thank you for purchasing our product!*

Please refer and use this assembly instruction to assemble the product. Contact our customer service department in case there are any missing or damaged parts or hardware. Replacement parts are normally shipped within 2 or 3 days.

### ASSEMBLY REQUIREMENT

1-Person Assembly  
10 Minutes Assembly Time (Approximate)  
Tools Required: **Allen Wrench (provided)**



### ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are complete before you start assembling.
3. Place all components on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

### SAFETY PRECAUTION

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.


### TIPS FOR ASSEMBLY

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior and finish of the furniture.
3. Please check all of the parts and quantities are included before assembly. Contact customer service for missing parts.
4. Identify all of the parts, hardware and quantities required for each step.
5. During assembly, do not over-tighten any fittings as this may cause damage.
6. **DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.**
7. Always place the product on a flat surface.
8. Do not sit or stand on the partially assembled product, only use the product for which it is intended.

### CARE AND USE


- Recommended for indoor use only.
- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.

# ASSEMBLY INSTRUCTIONS



**NOTE: Do not fully tighten any screws until all screws are threaded for fitment.**

Assemble stool base by attaching both halves of stool base together using Screws (B) and (C) as shown above, making sure not to tighten screws fully. Once all screws are in place, tighten firmly using Allen Wrench (A).









While sitting, place chair seat upside down in your lap with backrest hanging over knees. Align chair base with holes and secure the legs to the seat using washers (E,F) and screws (D) as shown. **NOTE: First hand tighten all 4 screws and then finish with an Allen wrench.**



Place stool upright, and carefully test for sturdiness. Pump your fist and do a victory dance - you've earned it. Enjoy!

- RECOMMENDED FOR INDOOR USE ONLY.
- ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE CHAIR AS STEP STOOL OR LADDER.
- DO NOT USE CHAIR UNLESS ALL BOLTS AND SCREWS ARE TIGHT.
- AT LEAST EVERY SIX MONTHS CHECK ALL BOLTS AND SCREWS TO BE SURE THEY ARE TIGHT.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USING THE PRODUCT UNTIL REPAIRS ARE MADE WITH FACTORY-AUTHORIZED PARTS.
- FAILURE TO FOLLOW THESE WARNINGS CAN RESULT IN SERIOUS INJURY.

PARTS CHECKLIST					
A	B	C	D	E	F
					
Allen Wrench	2 M8X14MM	2 M6X30MM	4 M6X25MM	4 Crush Washers	4 Washers