











# Assembly Instructions

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

## COMPONENT LIST:

FIGURE	DESCRIPTION	QTY
	Hardware Bag	1 pce
	Chair Back	1 pce
	Wood Seat	1 pce
	Seat Frame	1 pce
	Front Legs	2 pcs

## HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		JCBC Bolt(Short)	2 pcs
2		JCBC Bolt(Long)	8 pcs
3		Lock Washer	10 pcs
4		Flat Washer	10 pcs
5		Allen Key	1 pce


This product will take 15-20 minutes to assemble.

### Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening

### NOTE:

1. Two or two people are needed for assembly
2. Please keep all hardware parts out of the reach of children.




# Assembly Instructions

## ASSEMBLY :


### STEP 1

Step1: Attached wood seat to the chair back using the provided hardware as shown on Fig.1.1 and Fig.1.2.

Step2: Attached front legs (Left and Right) to wood seat the provided hardware as shown in Fig.2.




### STEP 2



### STEP 3

3.1- Turn the chair to standing position.

3.2- Check it's balance and tighten all screw and bolts to complete the assembly.



Assembly is now Completed.

#### CARE INSTRUCTION

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.