








1




Do not tighten any of the bolts until the item is fully assembled



Screw on bolts as shown in the picture, and tighten bolts with approximately 70% of required torque



3



The four black plastic feet are adjusted, you can turn them and adjust its height to help to make the chair stable

2

Place Chair on a totally flat surface and Re-tighten bolts again with 100% of required torque until all screws do not turn anymore



4

After finishing assembling, if the four legs are still not on the same level, pls try to switch the position of two front legs A or switch the position of two back legs B.

