


Assembly Instructions

COUNTER HEIGHT BENCH

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

COMPONENT LIST:

FIGURE	DESCRIPTION	QTY
	Hardware Bag	1 pce
	Bench Seat	1 pce
	Bench Left Leg	2 pcs
	Bench Right Leg	2 pcs
	Bench center Leg	2 pcs
	Side Stretcher	4 pcs
	Center Stretcher	3 pcs

HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		JCBC Bolt (Short)	4pcs
2		JCBC Bolt (Long)	8pcs
3		Lock Washer	12pcs
4		Flat Washer	12pcs
5		Flat Head Wood Screw	14pcs
6		Allen Key	1 pce
7		Glue	1 pce


This product will take 15-20 minutes to assemble.

Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening

NOTE:

1. Two or two people are needed for assembly
2. Please keep all hardware parts out of the reach of children.



Assembly Instructions

COUNTER HEIGHT BENCH

ASSEMBLY :


STEP 1

Turn the Bench Seat upside down on a soft protective surface such as carpet.

1.1-Attach Center Stretcher to middle of legs by using the provided hardware as shown in Fig.1.1

1.2-Attach Center legs to the middle of Bench Seat using the provided hardware as shown in Fig.1.2

1.3-Secure the center stretcher and center legs using the provided hardware as shown in Fig.1.3




STEP 2

2.1- Attach side and center Stretcher to the Left and Right legs by using the provided glue as shown on Fig.2.1

2.2- Attach Left and Right legs to the Bench Top using the provided hardware as shown on Fig.2.2


2.3- Secure the stretchers and legs by using the Pan Head Screw as shown on Fig.2.3



STEP 3

3.1- Turn bench to upright position.

3.2- Once bench is fully balance fully tighten all bolts.



Assembly is now Completed.

CARE INSTRUCTION

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.