


INSTRUCTION MANUAL

Wooden Garden Potting Bench Table

NOTICE

Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- Check all parts are present before you start to assemble the product. Place small parts on a tray or similar to ensure they are not lost.

The manufacturing process can very occasionally result in sharp edges/waste material so please take care when assembling this product.

- Ensure your product is sited on level ground. Failure to do this may put additional stress on connections and joints and in time could cause them to fail.
- In high winds, moved to a sheltered position and/or securely staked down.

Customer Service

Please Contact Us if You Need Any Helps

About Our Wood

Our products uses only premium lumber,
ensuring the safest product for your use. Although we take great care in selecting the best quality lumber available, wood is still a product of nature and susceptible to weathering which can change the appearance of your set.

What causes weathering? Does it affect the strength of my products?

One of the main reasons for weathering is the effects of water (moisture); the moisture content of the wood at the surface is different than the interior of the wood.As the climate changes, moisture moves in or out of the wood, causing tension which can result in checking and or warping.You can expect the following due to weathering.These changes will not affect the strength of the product:


1. Checking is surface cracks in the wood along the grain.

2. Warping results from any distortion (twisting, cupping) from the original plane of the board and often happens from rapid wetting and drying of the wood.

3. Fading happens as a natural change in the wood color as it is exposed to sun-light and will turn a grey over time.

How can I reduce the amount of weathering to my products ?

Sunlight will break down the wood or coating, applying a water repellant or stain on a yearly basis is important maintenance. (see your local stain and paint supplier for a recommended product)



PARTS

1






Table top 1 PC

2




Side Panel 2 PCS

3




Back Top Panel 1 PC

4




Back Bottom Panel 1 PC

5




Front Door Right 1PC

6




Front Door Left 1PC

7




Front Door Top 1PC

8




Front Door Bottom 1PC

9




Middle Shelf 1PC

10



Bottom Shelf 1PC

11



Sill Bar 2PCS

HARDWARE

a

M4x35mm
SCREW



24 PCS

b

M4x60mm
SCREW



4 PCS


c

M6x55mm
BOLT SET




8 PCS

d



4 PCS

e



2 PCS


f

M4x25mm
BOLT




4 PCS

Note:To Save installation time,It's Reconmend to identify Compoments before assembly!




PRODUCT ASSEMBLY


1



2 Side Panel 2 PCS



9 Middle Shelf 1PC





10 Bottom Shelf 1PC



c M6x55mm BOLT SET

8 PCS






PRODUCT ASSEMBLY


2

3



Back Top Panel 1 PC

4




Back Bottom Panel 1 PC

a M4x35mm SCREW




8 PCS




PRODUCT ASSEMBLY


3




Front Door Right 1PC




Front Door Left 1PC




Front Door Top 1PC



Front Door Bottom 1PC



4 PCS




PRODUCT ASSEMBLY

4

ⓐ M4x35mm
SCREW






6 PCS




PRODUCT ASSEMBLY

5

1	11	a
		M4x35mm SCREW 
Table top 1PC	Sill Bar 2PCS	10 PCS






PRODUCT ASSEMBLY

6

e




2 PCS

f

M4x25mm
BOLT



4 PCS




PRODUCT ASSEMBLY


7

d



4 PCS





Adjust feet height to ensure table are in horizontal position