




I870101413

Packages may not
arrive at the same time
Do not open until all
packages are received



**Tools required
(not included)**



2 people for assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING

In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)

Do not allow children to climb or hang on the furniture

Do not open more than one drawer at a time

Do not place heavy items in the top drawers

Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

please note that only the anti tip strap is provided.

You will need to provide wall plugs and screws applicable for your wall type


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVERTIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.

4




⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

















This is a permanent label.
Do not remove!

















ASSEMBLY OVERVIEW













PART LIST (BOX-1/2)

① X1 PC 	② X1 PC 	③ X1 PC 
④ X1 PC 	⑤ X1 PC 	⑥ X1 PC 
⑦ X1 PC 	⑧ X1 PC 	⑨ X1 PC 
⑩ X2 PCS 	⑪ X1 PC 	⑫ X1 PC 
⑬ X1 PC 	⑭ X1 PC 	












PART LIST (BOX-2/2)

⑮ X1 PC 	⑯ X1 PC 	⑰ X1 PC 	⑱ X2 PCS 
⑲ X1 PC 	⑳ X2 PCS 	㉑ X1 PC 	
㉒ X1 PC 	㉓ X1 PC 	㉔ X1 PC 	
㉕ X1 PC 	㉖ X1 PC 	㉗ X1 PC 	
㉘ X1 PC 	㉙ X1 PC 	㉚ X2 PCS  270*115*43mm	

HARDWARE LIST

A  $\varnothing 6 \times 35 \text{mm}$	B  $\varnothing 15 \times 9 \text{mm}$	C  $\varnothing 20 \text{mm}$	D  $\varnothing 6 \times 30 \text{mm}$
52+5 PCS	52+5 PCS	29+1 PC	28+4 PCS
E  $\varnothing 3.5 \times 30 \text{mm}$	F  $105 \times 15 \times 25 \text{mm}$	G  $M4 \times 16 \text{mm}$	H  $M4 \times 18 \text{mm}$
8+1 PCS	4 PCS	4+1 PC	4+1 PC
J  J-1 $24 \times 32 \times 1.2 \text{mm}$ 2 PCS		K  $70 \times 17 \times 13 \text{mm}$ 1 PC	
J-2  $\varnothing 3.5 \times 12 \text{mm}$ 8+1 PC		L  $\varnothing 3 \times 14 \text{mm}$ 2+1 PC	
M  $30 \times 22 \times 1 \text{mm}$ 2 PCS	N  $\varnothing 3 \times 12 \text{mm}$ 26+3 PCS	O  $\varnothing 5 \times \varnothing 7 \times 17 \text{mm}$ 4+1 PC	P  $\varnothing 5 \times 40 \text{mm}$ 12+2 PCS


HARDWARE LIST

Q  1 SET	R  Ø3.5*12mm 6+1 PC	S  25*Ø12mm 4+2 PCS	T  61.5*57*Ø3mm 6 PCS
U  14*14mm 28+2 PCS	V  Ø3*16mm 28+2 PCS	W  Ø12*4mm 6+1 PC	 1 PC
X  1 SET X-1 (72*24*1.5mm) X-4 (Ø4*40mm) X-3 (Ø3.5*12mm) X-2 (Ø8*35mm)			
DL  12" 2 PCS		DR  12" 2 PCS	
CL  12" 2 PCS		CR  12" 2 PCS	




2


Cx4



Fx1




Gx2









Nx6




DLx1




DRx1



3





A x4








B x4








E x4




4


Cx4	Fx1	Gx2
		
Nx6	DLx1	DRx1
		



5




Kx1




Lx2



6




X



Safety Strap Kit
1 SET

(X-1)



72*24*1.5mm
Angel Iron
2 PCS


(X-3)




Ø3.5*12mm
Short Screw
2 PCS

7



Rx4




8



Ax3





9




Bx3





Cx3





10



Ax8




11




Bx4





Cx4



Dx2



12




Bx4




Cx4




Dx2




13




14




15




16




17





Dx4




Px4




18



Ax8




19



CLx2


CL




Nx6




7



20




Ax7




7


A




21




CR x2






Nx6




22




Ax11




23




A x2



B x2



24





B x7



C x2




D x3





C x2


Back groove is on the opposite side.




25




26




27




A x4



A




28




B x4




Top Edge



29




Bx4





30

Wx6



31



At Least 2 Person.



Bx8





Cx6




Dx6



Back groove is on the opposite side.




32




J-1 x2




J-2 x8




33




Qx1



Rx2





34




U x28



V x28







35




S x4





Fx2	Mx2
	
Hx4	Nx2
	



37








Ox4




The shelf can be adjusted up and down with three heights.


38





X	X-2	X-4
		
Safety Strap Kit 1 SET	Wall Anchor 2 PCS	Ø4*40mm Long Screw 2 PCS

Safety strap kit (X) must be installed to prevent tipping, damage and/or injury.



A Guide to Wall Mounting & Fixings

Important note:



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

If plastic wall plugs (rawl plugs) are supplied with your product, eg:



these are suitable for use in masonry walls

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to **using the incorrect fixings is the responsibility of the installer.**

Make sure that the screws and wall plugs being used are suitable for **supporting your unit. Consult a qualified tradesperson if you are unsure.**




Hints:

1. General rule: always use a larger screw and wall plug if you are not sure.
2. Ensure you use the recommended drill bit to match the wall plug and hole size.
3. Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
4. **Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.**
5. **Ensure wall plugs are well fitted and are a tight fit in the drilled hole.**

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No. 1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, **use a specialist fitting in this case.** For light loads, general purpose wall plugs can be used.

No. 3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No. 5 "Hammer Fixing" wall plug




For use with walls stuck with **plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.**

No. 2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No. 4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No. 6 "Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.