


Product Installation Instruction

B255221W-1-US & B257221W-1-US

A Required Tools

1



Spirit Level

2



Electric Drill

3



Wrench

4




Silicone Gun

5



Marker

6



Measuring Tape

B Installation Steps

1/ UNPACK THE BATHTUB

Carefully remove the bathtub from the packaging and inspect for damage.




2/ INSPECT THE INSTALLATION AREA

Ensure the floor is level and free of defects. Verify that the drain outlet has been pre-installed in the correct location.




3/ ADJUST THE SUPPORT FEET

Adjust the support feet using a spirit level until the bathtub is perfectly level.



4/ SECURE THE SUPPORT FEET

Secure the support feet firmly to ensure stability.



5/ VERIFY DRAIN ALIGNMENT

Check that the bathtub drain aligns correctly with the floor drain pipe.




6/ TEST FIT THE BATHTUB

Position the bathtub in the installation area and perform a test fit.




7/ CONNECT THE DRAIN PIPE

Connect the bathtub drain assembly to the drainage system.



8/ WATER LEAK TEST

Fill the bathtub with water and inspect the drain and overflow system for leaks.



9/ APPLY SILICONE AND FIX THE BATHTUB

After confirming proper drainage and no leaks, apply silicone sealant to secure the bathtub.



10/ ALLOW 24 HOURS CURING TIME

Allow the silicone sealant to cure for 24 hours before using the bathtub.



C Attention

POINTS FOR ATTENTION BEFORE INSTALLATION

- 1.To avoid quality dispute, please kindly check product before installation. Or BRAVAT should not be liable for any quality issue raised after installation.
- 2.Please read the instruction carefully before beginning to install.
- 3.Please follow steps in the instruction to install this product or may result in costly mistake. BRAVAT shall not be responsible for any loss from that mistake.
- 4.Professional help is required for installation of this product.

INSPECTION

- 1.Before starting installation, check and ensure bathtub, are free of leaks that may occur during delivery.
- 2.Check and ensure bathtub surface is free of hit and damage.

ATTENTION POINTS AT INSTALLATION

- 1.To facilitate maintenance and clean, we recommend to install bathtub on finished floor with ceramic tile or terrace with ground tile.
- 2.To facilitate install and maintenance bathtub's key parts like drainage system. DON'T wall up bathtub with cement or tiles.
- 3.DON'T remove bathtub protecting film during installation.
- 4.DON'T take bathtub out of package for installation until wall and floor preparation finished.
- 5.NO bulbs and open fires are allowed to place in bathtub during installation.
- 6.NO stuff like sand, cement or other sundries are allowed to place in bathtub as that would likely damage bathtub surface.
- 7.NO solvent like paint or glue are allowed to contact with bathtub.

MAINTENANCE

- 1.suggest to clean bathtub immediately after drainage complete, as soap, body fat and dirt are easy to be removed at the time before bathtub dry.
- 2.Suggest to clean bathtub frequently if using in high hard water area where high calcium content in water would leave yellow spot after dirt attaching on bathtub surface.

SUGGESTION TO REMOVE SCRATCH:

- 1.If scratch is slight, spray metal polish or car polish on scratch at first, and then use electronic polishing machine to resume glossy surface.
- 2.If scratch is deep, use 2000# abrasive paper to remove scratch at first, and then use same method as(1) to resume glossy surface.



ATTENTION

- ×Do not strike the bathtub with sharp objects.
- ×Do not disassemble any internal parts.
- ×Do not use strong acidic or alkaline cleaners, or sharp/rough materials, when cleaning the bathtub.
- ×Do not sit on the edge of the bathtub at any time to prevent tipping.

BRAVAT
BY DIETSCH 1873