





INSTRUCTION








End Table







Caution: Read owner's manual completely before assembly and use.


















Parts :

	PARTS	Q'TY
1		01
2		01
3		01
4		01
5		01
6		04
7		01

	PARTS	Q'TY
8		02
9		02
10		02
11		02
12		01
13		01


Hardware:

	HARDWARE	Q'TY
A		10
B		10
C		08
D		02
E		02
F		02
G		02
H		02

	HARDWARE	Q'TY
I		04
J		24
K		08
L		08
M		08


Step By Step Assembly Instructions

Step 1 :





Step By Step Assembly Instructions

Step 2 :




Step By Step Assembly Instructions

Step 3 :




Step By Step Assembly Instructions

Step 4 :



Step By Step Assembly Instructions

Step 5 :



Step By Step Assembly Instructions

Step 6 :

