


CROWNFUL

USER MANUAL

SHAVED ICE MACHINE

MODEL NO.: LQ-M21006A1



READ THIS MANUAL THOROUGHLY BEFORE USING AND SAVE IT
FOR FUTURE REFERENCE

TABLE OF CONTENTS

IMPORTANT SAFEGUARDS	1
GETTING TO KNOW YOUR SHAVED ICE MACHINE	4
BEFORE FIRST USE	5
OPERATING INSTRUCTIONS	5
CLEANING AND MAINTENANCE	8
TROUBLESHOOTING	8
WARRANTY INFORMATION	9
CUSTOMER SUPPORT	9

IMPORTANT SAFEGUARDS

GENERAL WARNINGS AND SAFEGUARDS

- ▲ To prevent property damage and personal injury, it is important that you read and follow all general warnings, safeguards and instructions.
- ▲ Read the instructions provided in this booklet thoroughly as this gives important information concerning the assembly, use and maintenance. Preserve this manual carefully for future reference.
- ▲ Unplug from outlet when not in use, before assembling or disassembling, and before cleaning.
- ▲ To protect against the risk of electrical hazards, do not immerse the Shaved Ice Machine in water or other liquids.
- ▲ This Shaved Ice Machine has a blade that is extremely sharp. Use extreme caution during assembly, operation, disassembly and while cleaning the unit. If the blade becomes broken or loose, do not use the appliance.
- ▲ Do not operate the Shaved Ice Machine or any electrical equipment with a damaged cord or plug, or after the unit malfunctions or is dropped or damaged in any manner. Return it to the nearest authorized service facility for examination, repair or adjustment.
- ▲ When the Shaved Ice Machine is used by or near children or individuals with certain disabilities, close supervision is necessary.
- ▲ Use only attachments that are included in the packaging of the Shaved Ice Machine. The use of other attachments may cause fire, electric shock or injury.
- ▲ Do not operate your appliance in an appliance garage or under a wall cabinet. When storing it in an appliance garage, always unplug the unit from the electrical outlet. Not doing so could create a risk of fire, especially if the appliance touches the walls of the garage or the door touches the unit as it closes.
- ▲ Do not allow children access to plastic packaging bags.
- ▲ This Shaved Ice Machine is intended for household use only.
- ▲ After unpacking the unit and before each use, make sure the mechanical parts of the unit and all its attachments are intact. Look for any foreign objects before operating the Shaved Ice Machine. In case of doubts, do not use the appliance and refer to the manufacturer.
- ▲ Use extreme caution to make sure that you never place your fingers or other items into the machine or the machine's moving parts.
- ▲ Do not operate the machine without ice.

- ▲ The machine has overheating protection. If the machine is found to be overheated during use, the machine will automatically turn off. Please wait for the machine's temperature to drop before using it again. (When the machine is being used continuously for 2 minutes or more, the "PUSH" button located on top will gradually heat up. This is a normal phenomenon as the motor is situated in the upper part of the machine.)
- ▲ Before plugging the appliance into a power source, make sure the voltage details marked on the appliance seal/plaque correspond to those of your power supply. The seal/plaque is located on the motor unit.
- ▲ This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- ▲ Do not use the machine around a hot surface or hot appliances. Keep the appliance away from stovetops, broilers, ovens or any other potentially hot appliance. Pay special attention to the electrical cord to prevent it from touching a hot surface.
- ▲ This appliance must only be used for the purposes it was designed for, i.e. for crushing/shaving ice in the home. Any other use must be considered improper and therefore dangerous. The manufacturer cannot be held responsible for any damages derived from improper, incorrect and unreasonable uses.
- ▲ The use of any electric appliance involves the observance of some basic rules.

IN PARTICULAR:


- ▲ Never touch the appliance with wet or damp hands.
- ▲ Never use the appliance barefoot.
- ▲ Never pull the electrical cable or the appliance itself to remove the plug from the electrical socket.
- ▲ Avoid all contact with any moving parts of the appliance. Never leave the appliance exposed to the elements (rain, sunshine, etc.).
- ▲ Never let children or those unable to operate the appliance use it unattended. Do not leave the unit unattended while plugged into a power source.
- ▲ Before any cleaning, maintenance, assembly or disassembly, make sure that the Shaved Ice Machine is disconnected from the main power supply by unplugging it.
- ▲ Should the appliance be out of order and/or operating inefficiently, switch it off and do not attempt to tamper with it. For any repairs, only approach the manufacturer and request the use of original spare parts. Failure to comply with the above might result in the compromised safety of the appliance.

- ⚠ Should you decide to stop using the appliance, it is advisable to render it unusable by cutting the electrical cable, after unplugging it from the main power supply.
- ⚠ Furthermore, it is also advisable to render all hazardous parts of the appliance harmless, particularly for children, who might play with the discarded appliance.
- ⚠ Installation must be carried out in compliance with the manufacturer's instructions. Incorrect installation can cause damage to people, animals or objects for whom the manufacturer may not be held responsible.
- ⚠ In order to avoid dangerous overheating, it is advisable to unwind the electrical cable completely and use the appliance as recommended in the "Usage Precautions" paragraph. Never leave the appliance plugged in when not needed. Unplug from the power supply plug whenever the appliance is not used.
- ⚠ Never obstruct the openings or slits for ventilation and heat dissipation.
- ⚠ Should the electrical cable of this appliance be damaged, have it replaced only by an after-sales service center authorized by the manufacturer, as special tools are required.
- ⚠ The manufacturer reserves the right to make any changes considered necessary for industrial, commercial or design improvements or to comply with particular standards. It is advisable to pay particular attention to those warnings highlighted with the symbol.

SAVE THESE INSTRUCTIONS

GETTING TO KNOW YOUR SHAVED ICE MACHINE

1) PRODUCT DIAGRAM



2) Package Contents

- 1 x Shaved Ice Machine
- 2 x Ice Molds with lids
- 1 x User Manual

3) SPECIFICATIONS

Model	Voltage	Power	Unit size(L×W×H)	Net weight	Gross weight
LQ-M21006A1	120V	60Hz 130W	7.28×7.28×11.02 in	3.52 lbs	4.23 lbs

BEFORE FIRST USE

1. Carefully unpack your Crownful Shaved ice machine. Remove plastic bags from all parts of the unit. Be sure that the unit has not been damaged during transport. Do not leave plastic bags around children.
2. Rinse the ice crusher cup (Figure A. 4) and ice molds (Figure A. 6) with water and a non-abrasive cleanser, and then dry thoroughly.
3. Clean the Shaved Ice Machine housing (Figure A. 3) with a moistened cloth.

NOTE: Do not soak or immerse the motor unit (Figure A. 2) in water or other liquid.

OPERATING INSTRUCTIONS

ASSEMBLY AND USE:

1. Always ensure that the appliance is switched off, and that it is not plugged into an electrical outlet before you assemble and dismantle the Shaved Ice Machine.
2. Fill the ice molds (Figure A. 6) with water. Place the ice molds on a level surface in the freezer until the water is completely frozen. Once frozen you will have a small round block of ice. If needed, additional ice molds may be purchased.
3. Take the frozen ice molds out of the freezer. Remove the frozen round ice block from the plastic ice mold.

NOTE: For the fluffiest ice, allow the ice blocks to thaw for about 5 -7 minutes before shaving. This will produce fluffier snow.

4. Take out the top part (Figure A. 1) and insert the Ice into the ice crusher cup (Figure A. 4).

NOTE: During the freezing stage, the block of ice may become dome- shaped. If this should happen, place the dome-shaped side of the ice block down into the machine. The flattest side of the ice block should be facing up.





5. Place the top part (Figure A. 1) on top of the ice. Plug the Shaved Ice Machine into an electrical outlet. Press and hold the on/off button while applying pressure to the top of the motor unit. The motor unit will begin to shave the ice block. To stop the motor unit from shaving, remove your hand from the on/off button.
6. Place an empty ice mold or any other fit sized bowl on the support base and under the Shaved Ice Machine Blade (Figure A. 5). The bowl or empty ice mold will be used to catch the shaved ice produced by the Shaved Ice Machine.

7. After shaving an ice block, a thin ice will remain inside the ice crush cup (Figure A.4). The remaining ice must be thrown away before a new ice block is inserted into the ice crusher cup (Figure A. 4). When removing the remaining ice block, use caution and pay special attention to the blade and avoid all contact with the blade to prevent injury to yourself or others.
8. Apply your favorite premium shaved ice flavoring and enjoy!
9. Unplug the Shaved Ice Machine from the electrical outlet immediately after use.

HELPFUL TIPS

1. Twist the ice mold with both hands and then turn it upside down and tap lightly, the ice block falls off easily.
2. The texture of the shaved ice depends on the pressing force and the degree of ice thawing.
 - When more force is applied, ice comes out faster and texture is thicker.
 - To produce fluffier snow, allow ice blocks to thaw for about 5 to 7 minute before shaving.
3. It is best to make recipes in advance as some will require time to cool.
4. Be sure that your syrup is completely cooled before drizzling over shaved ice.
5. Squeeze bottles work best to pour syrup over shaved ice.

MAKE A VARIETY OF DELICIOUS AND REFRESHING TREATS WITH EASE



RECIPES

You can purchase store-made snow cone flavors or try creating your own with the following recipes and simple suggestions.

Drizzle any of the following over freshly shaved ice ...and enjoy!

- Flavored drink mixes
- Chocolate syrup
- Pre-made juice smoothies
- Orange juice
- Grape juice

Simply scan the QR code below to get more recipes.



CLEANING AND MAINTENANCE

1. The shaved ice machine must be off and unplugged before cleaning or storing.
2. The motor unit (Figure A. 2) may be cleaned with a slightly damp cloth but do not soak or immerse the motor unit in water or other liquid. DO NOT wash the motor unit (Figure A. 2) in a dishwasher.
3. Wipe main housing and ice crusher cup with a clean damp cloth.
4. During cleaning, use caution and pay special attention to the Shaved Ice Machine blade and avoid all contact with the blade to prevent injury to yourself or others.
5. Ice molds (Figure A. 6) are dishwasher safe.

TROUBLESHOOTING

TROUBLESHOOTING	POSSIBLE SOLUTION
1) The shaved ice machine does not work. 2) The shaved ice machine stopped working suddenly.	1) Check whether the socket and the power cord plug are well connected. 2) Check whether the power cord is in good condition. If the power cord is damaged, it must be replaced by the manufacturer or its maintenance department or similar professionals to avoid danger. 3) Please allow it to cool down and try it again after an hour. The machine has overheating protection. When used continuously, it will stop the machine from turning on but it will work again after it has cooled down.

After analyzing the above phenomena and the fault still cannot be eliminated, please contact the customer support team at support@crowndful.com. It is strictly forbidden for non-professionals to disassemble the machine by themselves.

WARRANTY INFORMATION

We grant 1 year warranty on the product commencing on the date of purchase. Within the guarantee period, we will eliminate any defects in the appliance resulting from faults in materials or workmanship. Please contact us at: support@crowndful.com to launch a warranty claim.

This guarantee does not cover: damage due to improper use, normal wear or use as well as defects that have a negligible effect on the value or operation of the appliance. The guarantee becomes void if repairs are undertaken by unauthorized persons and if original product parts are not used.

CUSTOMER SERVICE

1. If you have any product questions or concerns, please don't hesitate to contact us directly at support@crowndful.com or visit our website at: www.crowndful.com.
2. We have a hassle-free warranty and customer service team for satisfactory solutions to any issue you might have.



*Thanks for trusting CROWNFUL
for your household and kitchen needs!*



(Have fun with Shaved Ice!)



START & MAKE fluffy & delicious shaved ice with CROWNFUL great recipes.



SUBSCRIBE to our newsletter to get yourself updated with latest great deals, gifts and valuable information about CROWNFUL products.
[Https://www.facebook.com/crownful.official](https://www.facebook.com/crownful.official)



GOT QUESTIONS or CONCERNS?
Please contact support@crownful.com

12
Months

WARRANTY ISSUE

Email: support@crownful.com

And we'll do our best to make you one of our HAPPY customers!

We remain at your service of CROWNFUL !!

<https://www.crownful.com/>



Scan to Follow Us



@crownful.official
Website: www.crownful.com