

CARE AND MAINTENANCE


1. Do not use acids or alkaline cleaning agents.
2. Sharp objects will damage and scratch the surface.
3. Wipe the surface with a soft, damp cloth.
4. Please make sure that you have all parts indicated before You begin assembly of this item.
5. This item should be assembled on a soft surface to prevent Scratching the finish during assembly.
6. This item may require periodic tightening.

Need a part? Call TOV at 516-888-3355 or email service@tovfurniture.com









NIRSA CHAIN LINK 3-TIER CHANDELIER

TOV

NIRSA CHAIN LINK 3-TIER CHANDELIER **ASSEMBLY INSTRUCTIONS**




Part List and Hardware List


PART	DESCRIPTION	PICTURE	QUANTITY
A	CANOPY		1x
B	MOUNTING PLATE		1x
C	SIDE SCREW		2x
D	SCREW		2x
E	CONNECTOR		3x
F	METAL CORD GRIP		2x
G	METAL FRAME		1x
H	CHAIN LINK		63x

Preparation

Before beginning assembly of product, make sure all parts are present. Compare parts with the package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble the product. Estimated assembly time: 10 minutes



2




Note: Assembly starts from bottom ring.

Step 3 : Please hang 28 chain links (H) to the top tier of the chandelier.

Step 2 : Please hang 21 chain links (H) to the middle tier of the chandelier.

Step 1 : Please hang 14 chain links (H) to the bottom tier of the chandelier.

3



Chandelier is complete and ready to use.