


ASSEMBLY INSTRUCTION

ITEM: N715P473741




DINING TABLE



IMPORTANT NOTE :


- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP

Detail view




Part List		Hardware List	
A		1	Ø5/16" x 35mm Bolt (4pcs)
B		2	Ø5/16" x 45mm Bolt (1pcs)
C		3	Ø5/16" x 13mm x 1.5mm Spring Washer (8pcs)
D		4	Ø5/16" x 16mm x 1.5mm Flat Washer (8pcs)
E		5	Ø8 x 30mm Wooden Dowel (4pcs)
		6	4 x 58mm Allen key (1pc)

Step 1





Step 2





1	Ø5/16"x45 	1PCS	2	Ø5/16"x35 	4PCS
3	Ø5/16"x13x1.5 	5PCS	4	Ø5/16"x19x1.5 	5PCS
5	Ø8x30 	4PCS	6	4x58 	1PC

Step 3




1	Ø5/16"x40 	4PCS	4	Ø5/16"x19x1.5 	4PCS
3	Ø5/16"x13x1.5 	4PCS	6	4x58 	1PC



Step 4



Step 5




Place B in this position and align the drill holes accordingly then push the two table tops together.



Completed

Unlock in these positions and pull the table top to either side.



Hardware lock these positions.

