


ASSEMBLY INTRUCTIONS

MUSHROOM 5 LIGHT ARC FLOOR LAMP

4035, 4035SN, 4035WB

1. Carefully remove all parts from the box and lay on a clean flat surface.
Please see list of items included in the box.
2. Insert column (D) into base (C) and secure by sliding in washer (B) and nut (A) (which you will find attached to the bottom of the column) using the 17mm wrench provided (M).
3. Stand the now assembled base onto a flat surface.
4. Snap together male-female amp connectors (E&F) located at the top of the column (D) and the arm set (H).
5. Insert arc arms (H) into the column (D), extended arms facing forward toward the switch on the column, and secure with set screw (G) (you will find it attached to the arm set housing)
6. Insert shade (I) over socket (K) and secure with socket ring (L) which you will find attached to the socket.
7. Repeat steps in 6 above for each of the 5 arms.
8. Insert bulb (J) (included) to socket (K).
Bulb: C35 120V 4W 2700K E12 Dimmable, Flicker-free
9. Plug into a surge protected 110v outlet and enjoy the beautiful light!



ITEMS INLUDED / ARTICULOS INCLUIDOS							
D  TUBE TUBO	C  BASE BASE	A+B  WASHER ROSCA  NUT TUERCA	M  WRENCH TUERCA	H  ARC ARMS BRAZO DE ARCOS	G  THUMB SCREW TORNILLO	J  BULB BOMBILLA	L  SOCKET RING ANILLO DE CASQUILLO

IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Esta lampara tiene un enchufe polarizado (una navaja es mas ancha que la otra) como forma de seguridad para reducir el riesgo de un shock electrico. Este enchufe polarizado entrara en una conexi3n solo de un lado. Si el enchufe no entra en la conexi3n trate al reverso. Si aun asi no entra, contacte a un electricista calificado. Nunca use una extension a menos que el enchufe pueda ser conectado completamente. No altere el enchufe.