

WALL-MOUNTED MANUAL SCREEN

1. STRUCTURE

2. INSTALLING

Moving Parts of the drive must be installed higher than 25 mm above the floor. Choose a suitable place for installation. It is best to install two screws on the wall, the distance of the screws must be equal to that of the two rings and they should be at the same level. The rings must be strong enough to load more than 25kg of weight.

3. USEFUL INSTRUCTIONS

Hold the pulling ring tightly and pull down the screen slowly, then stop when the top black border comes out (or stop pulling whenever you want to stop), the screen can be auto-fixed. If it cannot be fixed, please operate it again according to the same method. After using, pull the screen down a little and it will go up and back into the housing.

4. WARNINGS

- a. The screen cannot be folded. Do not use fingers or hard objects to touch the screen surface. Do not splash milk, fruit juice or other chemical doses to the screen surface. Keep the screen far away from high temperature objects or fire.
- b. If the screen is dirty, wash it gently with a clean cloth or a cotton ball. Do not use organic solvents to clean the screen surface.
- c. When pulling the screen down, it must be done must be slowly and vertically. Do not pull it roughly. Stop pulling as soon as the black border is out or when the screen is jammed. Send the screen to the service center if the jammed is permanent.
- d. After using, retract the screen back to the housing in order to prevent dirt. If not using it for a long time, please remove the screen from the wall and pack it in a carton.

