



FLOOR LAMP

SAFETY & WARNINGS

Warning

- To reduce the risk of fire, electrical shock, or personal injury: always turn off and unplug this lighting fixture and allow it to cool before attempting to replace the light bulb.
- Do not touch light bulb while fixture is turned on.
- Keep flammable materials away from this lighting fixture.
- Never look directly at a lit bulb.

Safety Information

- Before assembly, place all parts out on a clean flat surface and inspect each part for defects that may have occurred during shipping.
- Inspect wire insulation for any cuts, abrasions or exposed copper that may have resulted during shipping. If there are any defects in the wire, DO NOT continue to assemble. Please send an email to our Customer Service immediately.
- Consult a qualified electrician if you have any electrical questions.
- Never drape clothes over the lamp.
- To reduce the likelihood of tipping over, we recommend placing the lamp behind furniture and keep children and pets away.
- To prevent children from suffocating and choking, keep them away from packing materials.
- Please read this manual carefully and keep it for future reference.

INSTALLATION

Step 1

Insert thread rods (B) into top of thick board (A), thread poles (C) to thick board.

Step 2

Insert thread rods (B) into top of long poles (C), attach thin board (D) to top of long poles (C) and secure by thread long poles (E).

Step 3

Insert thread rods (B) into top of long poles (E), attach thin board (F) to top of long poles (E) and secure by thread long poles (G).

Step 4

Insert thread rods (B) into top of poles (G), attach lamp holder board (H) to top of poles (G) and secure by thread short poles (I).

Step 5


Assemble lamp holder to board (H).

Step 6

Insert 4pcs shade sheets (J) to short poles (I).

Step 7

Attach the top frame (K) to top of short poles (I) by aligning holes and secure with screws (L) using M.



CLEANING & CARE

- Unplug lamp before cleaning.
- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.