


































Frame Parts List



Crystal Parts List



Part Number	Picture	Description	Qty	Diagram Number
		Crossbar 4" (Canopy part)	1	P1
		5/32-32 Screw	2	P2
		D4.75" Canopy plat	1	P3
		NUT	2	P4
		Set nut	1	P5
		metal washer	1	P6
		thread pipe	1	P7
		Shake rod	1	P8
		Power Cord 75"SPT-1 Black+ground wire	1	P9
		L6"metal tube	1	P10
		L12"metal tube	2	P11
		L16"metal tube	1	P12
		NUT	1	P13
		Ground Screw	2	P14
		thread pipe	1	P15
		Metal Wire Box	1	P16
		Set nut	7	P17

		Spring Seat	6	P18
		Hickey	1	P19
		thread pipe	1	P20
		Metal cover	1	P21
		Cap nut	1	P22
		Shake rod	6	P23
		metal lamp cap	6	P24
		E12 Socket	6	P25
		D23.25"metal ring	1	P26
		D18.5"metal ring	1	P27
		D14"metal ring	1	P28
		D9"metal ring	1	P29
		L3.5" chain	12	P30
		911-2.5"	98	A