


ANABEI

Assembly Guide




For video assembly guide,
scan the QR code:




or visit: assembly.anabei.com

Included Parts


The parts shown here are all the available options. The parts you have will depend on your custom order.




Primary Frame




Frame Cross Braces



Back Crossbar



Seat Deck




2x Frame Screws




Allen Key

Step 1: Assemble Frame


Before you begin, be sure that you're assembling on a non-abrasive surface, such as carpet or flattened cardboard.



With the loose uprights facing up, press down to expand the primary frame assembly.




Guide the loose upright poles through the holes on the frame ends.




Push the upright poles through the holes on the frame ends until they rest completely on the frame stops.

Step 2: Attach Cross Braces




Take two of the cross braces and place them on two adjoining sides as shown.

Slide the cross braces over the extended uprights.




Place a screw in the corner where the cross braces intersect, use the Allen key to tighten.

Next, slide the other two cross braces through the two fixed (non-velcro) sides of the seat deck as shown.





Step 3: Place Seat Deck




Flip the seat deck over and slide the seat cross braces down on the extended uprights.

Insert a screw in the remaining upright, where the cross braces intersect, use the allen key to tighten.




Tightly pull the velcro straps over the cross braces and secure underneath.

Step 4: Back Crossbar Installation



Insert the back crossbar into the two back uprights.



NOTE: The back crossbar has mounted detent pins. These pins need to be depressed to slide back into the uprights.



Step 5: Cover the Chair


Pull the padded duvet cover over the chair frame.

NOTE: Align the front of the seat pad with the front of the chair frame




Affix the side flaps around the frame using the velcro attachments

Next, pull the Slip Cover over the chair.





Zip the Slip Cover corner together at the rear of the chair.



Use the attached velcro straps at each corner to attach the cover to the plastic feet.

Parts Diagram

Item #	Part Name	Part Number	Qty
1	Primary Frame 15"	ACP - 401	1
1	Primary Frame 19"	ACP - 402	1
2	Frame Cross Brace	ACP - 403	4
3	Back Crossbar	ACP - 404	1
4	Seat Deck	ACP - 405	1
5	Frame Screw	ACP - 406	2
6	Allen Key	ACP - 407	1
7	Duvet 15"	ACP - 408	1
7	Duvet 19"	ACP - 409	1
8	Slipcover 15"	ACP - 410	1
8	Slipcover 19"	ACP - 411	1



Fabric Care Instructions

Machine Washable

All of our fabrics are machine washable. It must be Machine Wash – Cold. Use Cold Water and a mild detergent on a low/gentle cycle. Hang dry all covers. Please note that every machine wash adds wear to the fabric so it's recommended to opt for spot cleaning prior to machine washing whenever possible.

Spot Cleaning

We recommend spot cleaning with either an upholstery shampoo, foam from a mild detergent, or a mild cleaning solvent. Always hang to dry. When spills happen, blot immediately to remove the spilled material. Clean spots or stains from the outside to the middle of the affected area (this prevents circling). To prevent overall soiling, frequent vacuuming to remove dust and grime is recommended.