


Introduction

1. Introduction

We would like to congratulate you on the purchase of our product. As to secure the functioning and operating safety, please do read the instruction manual before taking it into operation.

2. Operation

- Unpack all parts carefully and check them for completeness. Make sure the fountain on a smooth flat surface.
- Connect the pump to the hose and place pump in bottom of fountain.
- The fountain with led, connect it to the pump and put the led forward to it popular place.
- Fill fountain with water and make sure pump is totally submerged.
- Plug the power cord into the power outlet and enjoy the wonderful atmosphere.



Attention! The illustration can deviate optically, since the pumps of various Agora-Tec Distinguish indoor fountain in size and appearance slightly. The operation is not affected.

3. Security tips

Obey absolutely valid regulations on the electrical security Never run pump dry Pumping inflammable, as well as all other aggressive liquids is prohibited.

Any altering of the product itself or changing of the components is forbidden, any warranty cannot be granted. For longer storage periods, the pump clean, rinse with clear water and dry at room temperature.

4. General and Safety:

- The indoor fountain should always be on a flat, clean surface.
- There must always be enough clean water in the well to be present to a to prevent the pump running dry.
- Distilled water is recommended, but not necessary.
- Always unplug the power cord before performing service or maintenance.
- Operate the pump only with the voltage specified on the Netzadapter.
- This no longer use if damaged the power cord, but should be disposed of immediately.
- Pull the pump tall never the cord.
- The pump should be installed so that this does not affect the casing of the well. There may be vibration and thereby loud, disturbing noises come.
- Check before installing the hoses for blockages and kinks.
- Never let the pump run dry.
- The pump must always be completely covered with water to an appropriate to ensure cooling. The water temperature should never be more than 35 ° C.
- Touch the drive unit never in operation.
- Do not turn on the pump when the Netzkabel or another part of the Product has a damage.
- The head of the pump can be set on some models on the lever on the pump will. For models with glass ball, this may be necessary to the ball in to bring movement.
- Please observe all instructions, then you will have continued enjoyment of the product.