


PRODUCT & CUTOUT DIMENSIONS

Model: FDWBI8067-24S | FDWBI8067-24BLK | FDWBI8067-24WHT



PRODUCT DIMENSIONS





PRODUCT & CUTOUT DIMENSIONS

Model: FDWBI8067-24S | FDWBI8067-24BLK | FDWBI8067-24WHT



CUTOUT DIMENSIONS

- The rough cabinet opening must be at least 24" (61 cm) wide and a maximum of 35" (88.9 cm) in height, and provide easy access to water, electricity and a drain.
- When installed in a corner location, a 2" (5.1 cm) minimum clearance is required between the side of the dishwasher and the adjacent wall, cabinet or other appliance.
- There must be a minimum clearance of 25 5/8" (65.1 cm) in front of the dishwasher to allow the door to fully open.




DIMENSIONS DU PRODUIT ET DES DÉCOUPES

Modèle: FDWBI8067-24S | FDWBI8067-24BLK | FDWBI8067-24WHT



DIMENSIONS DU PRODUIT



DIMENSIONS DU PRODUIT ET DES DÉCOUPES

Modèle: FDWBI8067-24S | FDWBI8067-24BLK | FDWBI8067-24WHT



DIMENSIONS DES DÉCOUPES

- L'ouverture brute de l'armoire doit mesurer au moins 61 cm (24 po) de largeur et au plus 88,9 cm (35 po) de hauteur, et permettre un accès facile à l'eau, à l'électricité et à un drain.
- Lorsqu'il est installé dans un coin, un espace libre d'au moins 5,1 cm (2 po) est requis entre le côté du lave-vaisselle et le mur, l'armoire ou tout autre appareil adjacent.
- Il doit y avoir un espace libre d'au moins 65,1 cm (25 5/8 po) devant le lave-vaisselle pour permettre à la porte de s'ouvrir complètement.

