



# ASSEMBLY INSTRUCTIONS

## Corner+Armless chair



### + Do Not Use Power Tools



### + Suggested Adults



#### NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

### 1 IMPORTANT SAFETY INFORMATION

**Do not** assemble the product if any of the following parts arrived damaged:

- part # - Corner base
- part # - Corner cushion
- part # - Armless chair base
- part # - Armless chair cushion
- part # - Chrome leg
- part # - Gold leg

**Do not** assemble if any of the following Hardware parts are missing:

- part # - Allen wrench
- part # - Bolt M8"\*35mm
- part # - Washer M8\*16mm
- part # - Connect metal plate


### 2 IMPORTANT ASSEMBLY INFORMATION

**Assembly Step** If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

### + Parts Included



- ① Corner base  
1pc

- ② Corner cushion  
1pc



- ③ Armless chair base  
1pc

- ④ Armless chair cushion  
1pc



- ⑤ Chrome leg  
8 pcs

- ⑥ Gold leg  
8 pcs



### + Hardware Included

- A** Allen wrench  
1 pc

- B** Bolt M8"\*35mm  
24pcs



- C** Washer M8\*16mm  
24 pcs

- D** Connect metal plate  
100\*75\*18mm  
2 pcs

