

INSTRUCTION MANUAL

Joyside 11 FT x 13 FT Double Roof Hardtop Gazebo

Series A01

IF YOU PURCHASED THE GAZEBO ONLINE AND HAVE ANY QUESTIONS OR CONCERNS
PLEASE CONTACT US WITH EMAIL OR WHATSAPP
service@joysidefurniture.com



WhatsApp QR Code

WARNING

To reduce the risk of serious injury, read the following safety information before assembling and using the gazebo.

Please check with your local governing authority/local municipal codes regarding installation of structures before assembly.

SAFETY INFORMATION

- This product is intended for domestic outdoor use only.
- The product should be placed on flat, horizontal ground.
- Ensure enough clearance around the product. Before assembling the product, find level ground not less than 6'(1.8 m) away from any structures or obstructions, such as fences, garages, houses, overhanging branches, laundry lines, or electrical wires.
- The gazebo is not to be regarded as part of a building/house structure. The gazebo is to be anchored onto the ground for added safety. Do not assemble the gazebo onto soil/earth ground. It is best advisable to have the gazebo built onto a wooden deck or concrete ground for stability. If it is to be build onto a wooden deck/ground, do ensure that the wooden deck/ground has a strong foundation. It is advisable to use appropriate floor plugs (not provided) to anchor the gazebo onto the wooden/concrete ground.
- Some structures may require two or more people to install safely. Check for underground utilities before digging or driving stakes into the ground.
- During installation, follow all safety warnings provided with your tools, and use safety glasses.
- In case you set up more than one gazebo, keep a minimum distance of 10' (3 m) between the gazebos.
- Any assembly or maintenance of the product must be carried out by adults only.
- Arrange necessary manpower when assembling or moving the product.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- Keep children and pets away while setting up the gazebo.
- Check all nuts and bolts periodically to ensure bolts/nuts are tightened.
- Repairing and replacing parts should be done by a qualified technician.

- This gazebo is intended for decorative and sunshade purposes only, and it is not designed to withstand harsh weather, including high winds, rain, and snow.
- Do not light any fires inside or near the product!
- Stay calm if fire breaks out. Search for the nearest exit. Do not return to the gazebo before firemen allow you to do so.
- Do not hang heavy weights on the roof frame.
- Do not climb onto the roof of the gazebo. Falling off the gazebo can result in serious injury.
- Retain the original packaging to store the gazebo.


PREPARATION

- Please read and understand this manual before any assembly. Before beginning assembly of product, make sure all parts are present. Compare parts with packaging contents list.
- If any part is missing, or if you have any questions, please contact us with email service@joysidefurniture.com.
- •When assembling wooden parts, do not overtorque the bolts to avoid splitting the wood.

SEE IMAGE ILLUSTRATION

- •Place all parts from the box in a cleared area and position them on the floor.
- •Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete.
- •Read each step carefully before beginning any assembly and make sure you understand each step. If you are missing a part, please contact us with email service@joysidefurniture.com.

Note: The gazebo needs to be installed in cooperation with five people. The following tools are not included and needed for assembly:



Part List

Description	Label	Qty	Part Image
Outer Right Long Beam	02	2	
Outer Left Long Beam	01	2	<u>:</u> :
Outer Left Short Beam	03	2	
Outer Right Short Beam	04	2	:
Inner Middle Beam	05	4	
Inner Short Beam (Long)	07	4	
Inner Short Beam (Short)	06	4	· · · · · · · · · · · · · · · · · · ·
Post	08	4	<u>\(\cdot \c</u>
Arc Support 1	10	4	· · ·
Arc Support 2	11	4	
Base Cover	В	4	
Base	С	4	
Small Roof Connector	D	1	
Big Roof Long Connector Tube	E1	2	disp.
Big Roof Short Connector Tube	E2	2	
Small Roof Oblique Beam	F	4	
Slanting Beam	G	4	7: · · · · · · · · · · · · · · · · · · ·

Middle Beam	Н	6	
Slanting Beam Connector	I	4	
Middle Beam Connector	J	6	
Hook	Р	1	
Small Roof long side Beam	L1	2	0 0
Small roof long side under blocking beam	L1-1	2	• • • •
Small Roof Short side Beam	L2	2	<u> </u>
Small roof Short side under blocking beam	L2-1	2	• • •
Big roof top Up beam	L3	8	0
Big roof top Under beam	L4	8	<u>o</u> o
Big roof top middle beam (long side)	L5	4	
Big roof left side under blocking beam	L6	4	0 0 0
Big roof right side under blocking beam	L7	4	0 0 0 0
Big roof middle side under blocking beam	L8	2	<u>s</u> <u>s</u>
Left Mosquito Netting Rod	M1	4	
Right Mosquito Netting Rod	M2	4	*
Middle Mosquito Netting Rod	М3	2	


Small Roof Left Panel	P1	4	
Small Roof Right Panel	P2	4	
Small Roof Middle Panel	P3	2	°
Left Big Roof Samll Panel	Q1	4	
Left Big Roof middle Panel	Q2	4	
Left Big Roof big Panel	Q3	4	
Big Roof Middle Panel	Q4	2	
Right Big Roof big Panel	Q5	4	


Right Big Roof middle Panel	Q6	4	
Right Big Roof Samll Panel	Q7	4	
Small Roof Middle Beam Cap	R1	1	
Small Roof Inclined Beam Cap	R2	4	
Inclined Beam Cap	R3	4	
mound layer 1	S1	6	0 10 0
mound layer 2	S2	4	0 11 0
mound layer 3	S3	10	0 111 0 111 0

Hardware Pack


Label	Description	Qty	Add	Part Image
AA	Bolt M10*205	8	1	
ВВ	Flat Washer M6	24	10	
СС	Screw M5*40	64	4	
DD	Non-slip Nuts M6	24	2	
EE	Screw M5*30	56	4	
FF	Bolt M6*20	212	10	
GG	Bolt M6*15	12	1	
НН	Bolt M8*35	16	1	
II	Screw M8*35	16	1	
JJ	Bolt M6*55	26	2	
КК	Bolt M8*25	24	2	
LL	Non-slip Nuts M10	8	1	


ММ	Flat Washer M8	16	4	
NN	Flat Washer M10	16	2	
00	Bolt M10*80	8	1	
PP	Stake Ф8*180	8	0	
QQ	Bolt M6*35	16	1	
RR	M3 Drill	2	0	
Z1	M6 Wrench	2	0	
Z2	Allen Key M8	1	0	
Z4	M10 Wrench	2	0	


























































































































































Noting: Please purchase the anchors from local hardware store if anchor the gazebo to concrete or wood. (Pls use expansion bolts to fix on the concrete ground or wooden deck.)





WhatsApp QR Code service@joysidefurniture.com