

Assembly Manual
Dining Chair

DC9001




Please read this manual carefully before any operation and keep it properly for future use.


Assembly-note:




1 Put a protective mat on the ground and handle the product with care.




2 Two people are preferred.



3 Contact us if you have any confusions




Exploded diagram:



1	Backrest	1PCS
2	Seat	1PCS
3	Right batten	1PCS
4	Left batten	1PCS
5	Front Legs	1PCS

Accessory list:

A		B			
					
Bolt	12+1	Allen wrench	1		


Note:The number after "+" sign indicates the extra piece(s).


Step1：

Use B to connect （3） and （4） to （5）, screw to about 50%, can not lock.,this will allow you slight adjustments during the assembly.

1








(x4)

Step2：

Attach the assembled parts of Step1 with A and （1）, DO NOT fully tighten the bolt suntilallof the mare in the correct holes. This will allow you slight adjustments during the assembly.

2

50%





Ⓐ (x4)

Step3：
Use A to link the seat to the bottom frame, and lock all screws, Tighten all bolts completely.Then adjust the height of the foot mat to balance it.

3








(x4)

Done



Warning

- Please keep the product away from children while assembling.
- Do not let children play or jump on the product.
- Do not stand on the item or use as a step ladder.
- Prior to use, please check to see if there's any loosening screw or part.
- Make sure that each screw and part is correctly installed and securely fastened.

Care and Maintenance

- Use a soft clean cloth that will not scratch the surface when dusting
- There's no need to use furniture polish.If you need,test it first in an inconspicuous area.
- Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately.
- Gently blot the spill with a soft clean cloth to avoid rubbing.

Further advice about the furniture care

- It is best to keep your furniture in a climate-controlled environment.
- Extreme temperatures and humidity changes can cause fading.warping, shrinking and spitting of wood.
- We recommend to keep furniture from sunlight exposure to avoid possible surface damage.
- Proper maintenance and cleaning at home will extend the life of your purchase.
- Following these important and helpful tips will help retain your furniture's performance even when it ages. Periodically(every 90 days) make sure the screws are fully tightened.