


9 Piece Dining Set





**FOR REPLACEMENT PARTS OR HELP WITH
ASSEMBLY PLEASE CONTACT US
PLEASE ENSURE TO HAVE THE MODEL #
FROM THE PACKAGING OR INSTRUCTION BOOKLET**

**TO RETURN THE PRODUCT:
PLEASE CONTACT THE RETAILER
WHERE THE ITEM WAS PURCHASED FROM**

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of assembly.

CARE and MAINTENANCE

To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth. Dust with soft dry cloth.


Do not use ammonia-based cleaning products, as they will damage the finish.

Do not leave liquids or damp cloths on this furniture.

To avoid dulling of the finish, do not place furniture in direct sunlight.



Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.

54 INCH SQUARE DINING TABLE



PRE-ASSEMBLY INFORMATION

PARTS DESCRIPTION


<div data-bbox="102 255 150 315">A</div> <div data-bbox="118 450 826 712"></div> <div data-bbox="453 869 539 947">TOP QTY 1</div>	<div data-bbox="863 255 911 315">B</div> <div data-bbox="1158 409 1230 775"></div> <div data-bbox="1171 869 1257 947">LEG QTY 4</div>
--	--

NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

PRE-ASSEMBLY INFORMATION


HARDWARE DESCRIPTION

1



ALLEN KEY BOLT
M8 X 70 mm
QTY 8 SETS


2



ALLEN KEY
QTY 1


NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

COMPONENTS – KEY DIAGRAM



ASSEMBLY


STEP 1



1. Attach Legs (B) to Top (A).
2. Use 8 Allen Key Bolts (1) to secure part (A) and (B).
3. Use Allen Key (2) to tighten Allen Key Bolts. Do not over-tighten.


ASSEMBLY

STEP 2



Note: Levelers on bottom of legs can be adjusted if floor is uneven.


2 PACK DELUXE PARSON CHAIR



PRE-ASSEMBLY INFORMATION


PARTS DESCRIPTION

1



CHAIR BACK
QTY 1

2



SEAT CUSHION
QTY 1

3




FRONT LEG
QTY 2

NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

PRE-ASSEMBLY INFORMATION


HARDWARE DESCRIPTION

A




ALLEN KEY SCREW
M6 X 50 mm
QTY 2

B



ALLEN KEY SCREW
M6 X 55mm
QTY 4

C



ALLEN KEY SCREW
M6 X 100 mm
QTY 4

D



ALLEN KEY
QTY 1

E



FLAT WASHER
QTY 10

F




LOCK WASHER
QTY 10

NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

ASSEMBLY

STEP 1




Attach Seat Cushion (2) to Chair Back (1) by inserting Allen Key Screws (A) and two Washers (E) and (F).

Use Allen Key (D) to tighten.

ASSEMBLY


STEP 2



Secure Seat Cushion (2) to Chair Back (1) using Allen Key Screws (C) and four Washers (E) and (F).
Use Allen Key (D) to tighten.

ASSEMBLY


STEP 3



Attach Front Legs (3) to Seat Cushion (2) using Allen Key Screws (B) and four Washers (E) and (F).
Use Allen Key (D) to tighten.

ASSEMBLY


STEP 4



Attach fabric with velcro to bottom of seat.

ASSEMBLY

STEP 5



Turn Chair right side up.

WARRANTY

Thank you for purchasing our product. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.)

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.