

USER'S MANUAL





3 Pieces Wicker Bistro Set

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.




Before You Start


- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



Part List




1 x2 pcs
Backrest



2 x2 pcs
Left Leg Frame


with 2 holes on this place




3 x2 pcs
Right Leg Frame




4 x8 pcs
Wooden leg




5 x1 pc
Table shelf




6 x2 pcs
Seat panel




7 x4 pcs
Armrest




8 x2 pcs
Pillow



9 x2 pcs
Seat Cushion



10 x1 pc
Table top




11 x4 pcs
Table legs




M6x25mm Bolt
Ⓐ x8pcs




M6x35mm Bolt
Ⓑ x16pcs




M6x55mm Bolt
Ⓒ x4pcs




M4x15mm Screw
Ⓓ x16pcs




M4x20mm Screw
Ⓔ x8pcs






M6x30mm Screw
Ⓕ x8pcs




Allen key
Ⓖ x2pcs












STEP 1:







STEP 2 :**STEP 3: X2**

STEP 4: X2





STEP 5: X2









STEP 6: X2**STEP 7: X2**

STEP 8: X2




STEP 9: X2



STEP 10: X2**STEP 11:**

STEP 12:



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.