


Owner Manual




Weight Limitation

200 LBS



Installation:
30 minutes.



Two Person

Thank You For Choosing Our Furniture

- ▀ If you have any questions or concerns,
don't hesitate to reach out to us. ▀

NOTE:

This brochure contains
IMPORTANT safety info.
Please read and keep it
for future reference.

MAINTENANCE AND WARNINGS



Before You Start

Please follow the steps below:

-  Check the packaging for any damage, deformation, or water stains. If there is significant damage, please contact us promptly.
-  Unpack the box and compare the contents with the parts list and hardware list to ensure all components and accessories are present and complete.
-  Please read the installation instructions carefully to understand the installation steps and precautions to ensure proper installation.
-  Clean the installation area in advance and ensure the ground is level and there is enough space to avoid damaging the furniture or making installation difficult.
-  Lay a protective mat on the ground to prevent scratching the floor during installation.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Precautions

- ⚠ This product is for indoor use only. Do not expose it to outdoor elements or high-humidity environments.
- ⚠ Keep the product away from high heat or open flames to prevent fire hazards.
- ⚠ Do not allow children to climb on the product, as this may cause tipping and result in personal injury.




Safety Warnings

- ⚠ If you notice any loose or damaged parts, stop using the product immediately and contact customer service.
- ⚠ Do not attempt to disassemble or replace any components yourself, as this may affect the stability and safety of the product.

Daily Maintenance


- Regularly clean the surface with a soft cloth to prevent dust accumulation.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Avoid exposing furniture to humid environments for extended periods. Use a dehumidifier or desiccant during humid weather.
- Avoid direct contact of furniture with water. If water is accidentally spilled, wipe it dry immediately.
- Avoid placing excessively heavy objects on the furniture: ensure the weight is within a reasonable load-bearing range.
- Avoid using sharp or rough items on the furniture surface to prevent scratches. Handle items gently when moving them.

Explosive view




Parts list


A x1 Top panel




B x1 Bottom panel




C x1 Rail




D x1 Cover panel




E x1 Panel



F x1 Panel




G x3 Shelf panel




H x1 Side panel




I x1 Side panel




J x1 Side panel















K x1 Side panel




Hardware pack



Hardware List


① x20+3 Bolt  L32mm	② x2 Bolt  L89mm	③ x4 Bolt  L25mm
④ x3 Screw  L25mm	⑤ x4 Screw  L14mm	⑥ x4 Wood dowel  L30mm
⑦ x4 Bracket 	⑧ x4 Screw  L16mm	⑨ x4 Anchor 
⑩ x4 Screw  L35mm	⑪ x2 Plastic tie 	⑫ x6+1 Iron angle 
⑬ x12+2 Screw  L15mm	⑭ x1 Screwdriver 	⑮ x1 Allen key 



Note: Before installing the screws, please first distinguish the length of the screw rods.

Step 1


Connect part C to part I with bolt ① tight bolt with allen key ⑮.





① x2	⑮ x1
D6x32mm	

Step 2


Insert part B to the groove of part I , Connect part C to part B with screw ④, tight screw with screwdriver ⑭.



④ x3	⑭ x1
	
D6x25mm	


Step 3

Connect part E to part I with bolt ①, tight bolt with allen key ⑮.




Step 4

Insert part G to the groove of part I.




Step 5


Connect part H to the unit with bolt ①, make sure part G/B in the groove of par H, tight bolt with allen key ⑮.



Step 6


Connect part D to part C with screw ⑤, tight screw with screwdriver ⑭.





⑤ x4	⑭ x1
	
D3x14mm	

Step 7


Connect part F to part K with bolt ①, tight bolt with allen key ⑮.






① x3	⑮ x1
	
D6x32mm	

Step 8


Connect part A to part K with bolt ①②, tight bolt with allen key ⑮.



① x2	② x1	⑮ x1
		
D6x32mm	D6x89mm	


Step 9

Insert part G to the groove of part K.




Step 10


Connect part J to the unit pre-assembled at step 9 with bolt ①②, tight bolt with allen key ⑮.



Step 11


Connect the unit pre-assembled at 6 to the unit pre-assembled at step 10 with bolt ③ and wood dowel ⑥, tight bolt with allen key ⑮.



③ x4	⑥ x4	⑮ x1
		
D6x25mm	D8x30mm	

Step 12



1. Connect part ⑦ to the unit pre-assembled at step 11 with screw ⑧, tight screw with screwdriver ⑭.
2. If you feel the bookcase is shaking, you can connect the part ⑫ to the unit with screw ⑬, then tight screw with screwdriver ⑭.




⑦ x2	⑧ x4	⑫ x6	⑬ x12	⑭ x1
	D3x16mm	D3x15mm	D3x15mm	

Step 13


Install Anti-tip device to the wall in this step.





1. Drill a hole in the wall with an electric drill.



2. Tap the plastic wall anchor into the hole with a hammer.



3. Secure the Anti-tip device to the wall with screws

⑦ x2	⑨ x4	⑩ x4	⑭ x1
			
		D4x39mm	

Step 14

WARNING

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- For use with televisions weighing 35 lb or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

