


ASSEMBLY INSTRUCTIONS

HYBC-010-B


HYBC-010-G

HYBC-010-W




Notice:


1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2



















Put a carpet on the floor
before unpacking



Estimate installation time:
30minutes








ASSEMBLY INSTRUCTIONS

PART LIST

Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
(A)		X1	(I)		X1
(B)		X1	(J)		X1
(C)		X1	(K)		X1
(D)		X1	(L)		X1
(E)		X1	(M)		X1
(F)		X1	(N)		X2
(G)		X1	(O)		X2
(H)		X2	(P)		X4






ASSEMBLY INSTRUCTIONS

PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
Q		X4	U		X1
R		X1	V		X1
S		X1	W		X4
T		X1			

ASSEMBLY INSTRUCTIONS

HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	 Ø8*30mm	X27+2	8	 Ø5*3/4"	X3
2		X53+5	9		X4
3		X29+2	10	 Ø1/4*1"	X4
4		X24+2	11		X4
5		X4	12		X1
6	 Ø3*14mm	X24+2	13		X2
7		X3	14	 Ø3.5*30mm	X8

ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

1





Ⓒ 1PC



Ⓓ 1PC




② 10PCS




ASSEMBLY INSTRUCTIONS


2




G 1PC





H 2PC



1 2PCS




3 10PCS



ASSEMBLY INSTRUCTIONS


3



(B) 1PC




(2) 8PCS




ASSEMBLY INSTRUCTIONS


4



(E) 1PC




(F) 1PC




(1) 4PCS



(2) 4PCS




(3) 4PCS




ASSEMBLY INSTRUCTIONS


5





① 1PC



① 5PCS




③ 8PCS




ASSEMBLY INSTRUCTIONS

6



(A) 1PC



(W) 4PC



Ø1/4*1"


(10) 4PCS



(11) 4PCS




(12) 1PCS



(1) 4PCS




(2) 4PCS




ASSEMBLY INSTRUCTIONS

7




① 4PCS



③ 4PCS




⑨ 4PCS




ASSEMBLY INSTRUCTIONS

8




① 1PC




① 1PC



② 3PCS




③ 3PCS




ASSEMBLY INSTRUCTIONS


9




(R) 1PC



(S) 1PC



(T) 1PC



(U) 1PC




(V) 1PC



Ø3.5*30mm

(14) 8PCS



ASSEMBLY INSTRUCTIONS

10




⑦ 1PCS




Ø5*3/4"

⑧ 1PCS




ASSEMBLY INSTRUCTIONS


11



(L) 1PC



(M) 1PC



(5) 4PCS





Ø3*14mm

(6) 8PCS








(2) 8PCS




ASSEMBLY INSTRUCTIONS

12



ASSEMBLY INSTRUCTIONS

13



① 8PCS



④ 16PCS



Ø3*14mm

⑥ 16PCS



⑦ 2PCS




Ø5*3/4"

⑧ 2PCS




⑬ 2PCS



ASSEMBLY INSTRUCTIONS

14




①

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm




②

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm



③

Up-Down Direction Adjustment:




Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS

15

Common Door Panel Issues:



ASSEMBLY INSTRUCTIONS

16

