



Installation Instructions

Assembly hardware



Installation Steps




Step 1: Align the water line with the fitting and tighten it by hand until snug

Step 2: Fit the fitting



Step 3: Tear off the tape, take out the gasket, and install it

Installation Steps



Step 4: Align and tighten at the fitting

Step 5: Find the red water-valve pipe, align it, and lock it tight



Step 6: Install the pump

Installation Steps



Step 7: Find the other red water pipe and align it to the pump

Step 8: Pass through the black cover plate



Step 9: Install the pump foot pads

Installation Steps



Step10:Position the pump and snap the black cover plate into place

Step11:Align and tighten the pump hose



Step 12:Find the black water pipe and align it for installation

Installation Steps



Step13:Place the end of the black water pipe at the position shown in the image

Step14:Find the fitting and install it in the designated position



Step 15:Locate the two lids for the filter compartment

Installation Steps




Step16:Install the small one on the bottom and the large one on top

Step14:Find the black cover plate, pass the black water pipe through it, and snap it into place




Step 18:Align the blue tube and press it down firmly

Installation Steps



Step19: Thread through the wiring hole

Step20: Position the water temperature sensor wire



Step21: Put the lid on—
fish-tank assembly is complete