

Elizabeth Table LED Lamp Assembly Instructions

Shade Assembly:

1. Unscrew the socket fastener (C) from the socket arm (B)
2. Place the glass shade onto the socket, and while holding the shade in place, screw the socket fastener back onto the socket arm until tight and the glass shade is securely fastened into place.

Wireless Charging:

Please make sure your wirelessly chargeable phone is placed at the center of the wireless charging area, and that it is connected. Phones with metal inside do not support a wireless charge. If your phone does not charge wirelessly, standard USB charging may be used.

BULB TYPE:

Includes 1x A19 5W LED bulb.

GENERAL PRODUCT INFORMATION:

This table lamp is only suitable for use in a dry location.

USB power: Max 5V=1A

Wireless charge power: Max 5V=1A

IMPORTANT SAFETY WARNING:

AS A SAFETY FEATURE, IN ORDER TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS LAMP HAS A POLARIZED PLUG. THIS MEANS ONE PRONG IS LARGER THAN THE OTHER AND WILL ONLY FIT ONE WAY IN A POLARIZED OUTLET. IF THE PLUG DOES NOT FULLY FIT INTO THE OUTLET, TAKE IT OUT AND FLIP IT OVER, REINSERTING THE PLUG WITH THE PRONGS REVERSED. IF THE PLUG STILL DOES NOT FULLY FIT INTO THE OUTLET, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE THIS LAMP WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED INTO THE CORD'S SOCKET. NEVER PHYSICALLY MODIFY OR ALTER THE PLUG ITSELF IN ANY WAY.

Thank you for purchasing this Brightech product. We guarantee all of our products with a best-in-class warranty for any manufacturer defects. If you need assistance or are unsatisfied with your purchase, PLEASE REACH OUT TO US DIRECTLY at wecare@brightech.com or file a warranty claim at <https://www.brightech.com/pages/warranty-request>

