


Coffee Table

Assembly Instruction - Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



CONTACT US

- In order to receive assistance more quickly, please provide

THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

Important – Please read these instructions carefully before starting the installation.

Before Assembly



Thank you for choosing our product!

To ensure a smooth installation process, please read this guide carefully to familiarize yourself with the required tools, materials, and installation steps.

Follow the relevant sections to avoid any damage caused by improper installation, and make sure to review all operation and safety guidelines for correct installation procedures.

Packaging Notice:

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.

Safety and Care Advice



Important :

Please read these instructions fully before starting assembly.

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal center.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.

Warning

In order to help prevent overturning, please follow these instructions.

- Use the anti tip strap or wall fixing method provided (if applicable).
- Do not allow children to climb or hang on the furniture.
- Do not open more than one drawer at a time.
- Do not place heavy items in the top drawers.
- Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose.
- Please note that only the anti tip strap is provided. You will need to provide wall plugs and screws applicable for your wall type.

Customer Service Guide



Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “Missing 5 pieces of M6×30mm screws.”

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with order details to **us**, with the subject line “Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:

1. Contact our customer service team.
2. Provide a description of the damage and include relevant photos or videos.

Resolution:

We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Helpful Tips


To process your issue efficiently, please prepare the following information:

- Order details (order number, purchase platform, purchase date).
- Clear photos or videos.
- We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.


Thank you for your trust and support!
We hope you enjoy using our product!

Parts List - Panels


Please check you have all the panels listed below




1 (100X42.6X1.2) cm X1




2 (100X10X1.2) cm X2




3 (42.6X8.8X1.2) cm X2




4 (50X21X1.2) cm X2




5 (28.2X21X1.2) cm X2




6 (100X45 X1.2) cm X1



7 (42.5X19.5X1.2) cm X2



8 (100X19.5X1.2) cm X2



9 (42.5X10X1.2) cm X1

Parts List - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  7*35mm Cam Bolt x 48	B  Camlock x 48	C  6*30mm Wooden Dowel x 54
D  Plastic buckle x 8	E  5*35mm Screw x 6	F  Strip light x 1
G  3.5*12mm Screw x 8		

Tools required

 Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws

mm




Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.

4



Assembly Instructions








Assembly Instructions

Step 1

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)








Secure the cam pin (A) to the part (1) with a screwdriver.

Step 2

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)





x2

Secure the cam pin (A) to the part (2) with a screwdriver.

Assembly Instructions




Step 3



x2

Insert wooden dowel (C) into part (3).



Step 4



Connect the top plate (1) to the cowl panel (3), insert and lock the cam lock (B).



Assembly Instructions

Step 5



Insert wooden dowel (C) into part (1,3).

Step 6






Connect components (2) to components (1, 3), insert and lock cam lock (B).

Assembly Instructions

Step 7



CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



Secure the cam pin (A) to the part (4) with a screwdriver.






Step 8



Insert wooden dowel (C) into part (5).




Assembly Instructions

Step 9



Connect components (4) to components (5), insert and lock cam lock (B).






Step 10



Connect components (4) to components (5), insert and lock cam lock (B).



Assembly Instructions

Step 11



As shown in the figure, the parts (D, G) for the lamp belt (F), secure to (4,5).


Step 12




Insert wooden dowel (C) into part (4,5).

Assembly Instructions

Step 13




B 
B x 6



Connect components (4,5) to components (1), insert and lock cam lock (B).

Step 14



C 
6*30mm
C x 8



Insert wooden dowel (C) into part (4,5).


Assembly Instructions

Step 15







Secure component (6) with screw (E) using a screwdriver.

Step 16



CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)







Secure the cam pin (A) to the part (6) with a screwdriver.

Assembly Instructions

Step 17

CAM-LOCK



Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



x2

Secure the cam pin (A) to the part (8) with a screwdriver.

Step 18





x2

Insert wooden dowel (C) into part (7).




Assembly Instructions

Step 19



Insert wooden dowel (C) into part (9).


Step 20




Connect components (7.9) to components (8), insert and lock cam lock (B).

Assembly Instructions

Step 21




B 
B x 5



Connect components (7,9) to components (8), insert and lock cam lock (B).

Step 22


C 
6*30mm
C x 8



Insert wooden dowel (C) into part (7,8).

Assembly Instructions


Step 23



B




B x 10



Connect components (7,8) to components (6), insert and lock cam lock (B).

Step 24



Assembly is complete.