





JT-A-104 ASSEMBLY INSTRUCTION



A x1



B x4



C x1




D x16
M8X20




E x1
5#


1



2



3



4

