
AX01



Email:service@delarkhome.com

General Guidelines



2 person required to assemble this product

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.
- If there is any damage after unpacking or you have any questions during assembly, please feel free to contact us at your earliest convenience. Our customer care team provides professional returns or exchanges as well as assembly guidance.

Notes

- This product is only intended for home use. The seller does not take any responsibility for damage or injury if user disregards this instruction.
- Please fix the product to the wall with the safety strap provided in case of toppling. Because construction materials vary, please consult a local professional for the most suitable way to fix your product to the wall.
- Prior to assembly, please check the product for defects or missing parts. Do not place unwrapped product directly on the floor to avoid paint peeling.
- It is recommended that the product be assembled by two people. Please assemble the product on soft surface to avoid damage to the product.
- Do not fully tighten the screws until you finish the assembly.
- Do not tighten screws with an electric drill as it may cause damage. Please use a screwdriver (not provided) only.
- After assembly, place the product in the ventilated place for a few days.
- Please check screws, bolts and connecting points periodically and retighten if necessary.
- Keep product surfaces away from sharp objects and corrosive chemicals.
- Protect the surfaces from heat sources and liquids with mats and coasters. Wipe off spilled liquids immediately. Put a pad under the paper when you write on it.
- Do not expose the product to strong sunlight and humidity in case of accelerated aging of lacquer and distortion.
- Do not place heavy objects on the product or shake it in case of distortion and paint peeling.
- Please seek assistance when moving the product. Do not pull or drag the product in case of damage or injury.
- Please fully disassemble the product when moving it to other places (such as moving to a new home) to prevent damage or injury. Please keep all original parts for reassembly.
- Please fully clean the product by cloth with a neutral detergent and wipe it with soft cloth.

Wamings

- Toppling of the product may cause severe or fatal injury.
- Stop using the product if any parts are missing or damaged.
- Children could only use the product under adult supervision. Children are not allowed to climb or play on the product to prevent body injury caused by toppling or mirror breaking.
- During the assembly, keep any small parts out of the reach of children in case of fatal danger caused by swallowing or inhalation.
- Keep all parts of packaging materials (films, plastic bags, foam boards, etc.) out of reach of children, especially toddlers and babies to avoid any potential danger (such as suffocation).

CUSTOMER SERVICE

If you encounter any questions or problems during the assembly process, please do not hesitate to contact us.

We strive to provide excellent customer support and will respond to your inquiries within 24 hours. Our team will offer you a suitable solution to address any concerns you may have.

Email: service@delarkhome.com

Email


You Tube



















SAFETY INSTRUCTIONS


- Please read the instructions carefully before using.
- Do not disassemble or refit the products.
- Press touch sensor button properly.
- Do not place the product in wet environment in case of shortening of battery life.
- Keep the mirror dry; moisture reduces the sensitivity of the product.
- Turn off the power before cleaning.The surface of the mirror should be cleaned with glass cleaner; please make sure the mirror is completely dry before using.
- Turn off the power and avoid direct sunlight if not used or stored for a long time.
- Far away from children's access.
- Make sure that your power adapter matches the mirror's voltage rating before using.
- Do not approach or put the product into the fire in case of fire or explosion.
- Stop using it immediately if an abnormal condition occurs.

PACKAGE 1 / 2: 39

PACKAGE 2 / 2: 1 / 2 / 3 / 4 / 5 / 6 / 7 / 8 / 9 / 10 / 11 / 12 / 13 / 14 / 15 / 16 / 17 / 18 / 19 / 20
21 / 22 / 23 / 24 / 25 / 26 / 27 / 28 / 29 / 30 / 31 / 32 / 33 / 34 / 35 / 36 / 37 / 38 Hardware + Manual





A x57+5	B x57+5	C x34+5	D x10+2	E x29+5	F x19+4	G x10	H x74+5
		 Ø8x30mm	 Ø6x30mm	 M4x30mm	 M4x40mm		 M3.5x12mm
I x7	J x2	K x2	L x2+2	M x2+2	N x4+2	O x10+2	P x16+2
			 M4x35mm	 M4x13mm		 M6x25mm	 M4x15mm
Q x1	R x8+2	S x8+2	T x4	U x2	V x1		
		 M3x16mm					



· Separate the slide bracket from the slide arm as per diagram.

1







G 2PCS H 6PCS

Turn180°


2






G 1PCS H 3PCS

3







G 2PCS H 6PCS

Turn180°


4






G 1PCS H 3PCS


5






B 3PCS


6






B 3PCS


7






G 2PCS H 6PCS


8







G 2PCS H 6PCS


9







10






11






A 1PCS C 1PCS


12



C 4PCS F 4PCS


13






A 1PCS C 1PCS


14






A 1PCS C 1PCS

15




C 4PCS F 4PCS


16



A 2PCS C 2PCS


17







A 2PCS C 2PCS


18



19









B 2PCS


20





A 2PCS C 2PCS

21





C 2PCS

F 8PCS

D 2PCS

22







B 11PCS

J 2PCS

M 2PCS


23





A 8PCS C 10PCS


24




T 4PCS

P 16PCS


25






B 7PCS


26



C 2PCS F 3PCS

27







C 2PCS

A 6PCS


D 2PCS

28







29


O
U
Q
39
R
S
6
38
37
R
S
R
S
R
S
38
R
S
R
S
R
S

R
S



O 10PCS
Q 1PCS
S 8PCS
R 8PCS
U 2PCS


30



V 1PCS


31







L 2PCS K 2PCS


32






33







34





35




36










37












38



39







I 1PCS

G 2PCS

H 8PCS

40






I 1PCS


G 2PCS

H 8PCS

41




x2





x2


E 8PCS

42













43














44


H
G
35
34
H
32
H


I
1PCS
G
2PCS
H
8PCS


45


H
G
35
34
H
33
H


I
1PCS
G
2PCS
H
8PCS

46







E 5PCS

D 1PCS


47






B 5PCS

48







A 5PCS

D 1PCS

49






I 1PCS


G 2PCS

H 8PCS

50



51



Note:

Three color lighting effects available. Press and hold the button to adjust brightness.


Lighted Mirror – Instructions for Use

⏻	Short press: cycle between warm light, cool light and neutral light Long press: when the light is on, press the key to adjust the brightness, and release the key to lock the brightness. (With brightness memory function)

Input voltage: DC 12V Power:12W

1. Connect power supply.
2. Press ⏻ switch to turn the light on/off.
3. Short Press ⏻ to switch between warm white, natural white and cold white color light.
4. Long press ⏻ to adjust the brightness.

52



Questions? Comments?

We are here to help!

Email: service@delarkhome.com