


User Manual





ASSEMBLY INSTRUCTION





ASSEMBLY INSTRUCTION


1

X1


2

X2


3

X1


4

X1


5

X1


6

X1


7

X2


8

X1


9

X1

10

X1

11

X1

12

X1



13

X1



14

X1


15



X1

PART LIST

A	B	C	D
			
ST6*40mm	9.5	∅6*30mm	ST5*40mm
24+2PCS	24+2PCS	20+2PCS	8PCS


E	F	G	H
			
	ST3.5*14mm	∅6*14mm	
4PCS	62+6PCS	8PCS	4PCS

I	J	K	L
			
	ST3*12mm	X1 X2 X2 X2 X2	
4PCS	4PCS	2PCS	2PCS

M			
			
	24	3#	
4PCS	1PC	1PC	


ASSEMBLY INSTRUCTION


STEP 1



A
ST6*40mm
10PCS

STEP 2






X2

C	A
	
Ø6*35mm	ST6*40mm
12PCS	8PCS

STEP 3





B

9.5
2PCS

ASSEMBLY INSTRUCTION


STEP 4






B
9.5
2PCS

STEP 5



A
ST6*40mm
6PCS


STEP 6



L	F
2PCS	ST3.5*14mm
	6PCS

ASSEMBLY INSTRUCTION


STEP 7



B

9.5
4PCS


STEP 8



C

Ø6*35mm
4PCS

STEP 9




B

9.5
2PCS


ASSEMBLY INSTRUCTION

STEP 10





C	D
Ø6*35mm	ST5*40mm
4PCS	4PCS

STEP 11



Note that this step requires two people to cooperate to install it.







D
ST5*40mm
2PCS

ASSEMBLY INSTRUCTION

STEP 12

Note that this step requires two people to cooperate to install it.






D	B
	
ST5*40mm	9.5
2PCS	7PCS


ASSEMBLY INSTRUCTION

STEP 13



B
9.5
7PCS

STEP 14





F
ST3.5*12mm
4PCS

ASSEMBLY INSTRUCTION

STEP 15


Note that you can paste the sponge pad according to your own needs.





M
4PCS

STEP 16




E	H
4PCS	4PCS

L	J	F
4PCS	ST3*12mm 4PCS	ST3.5*14mm 16PCS

ASSEMBLY INSTRUCTION


STEP 17



G
8PCS

ASSEMBLY INSTRUCTION


STEP 18



Note that this step requires two people to cooperate to install it.

3. Adjust this screw to make the door go up or down

2. Adjust this screw to make the door forward or backward




Note: After the door pane is installed,if the gap of the door is too large or too small, you can adjust this screw to adjust the gap of the door.

1. Adjust this screw to make the door turn left or right

F
ST3.5*14mm
16PCS


ASSEMBLY INSTRUCTION

STEP 19



Note that this step requires two people to cooperate to install it.

3. Adjust this screw to make the door go up or down



2. Adjust this screw to make the door forward or backward

1. Adjust this screw to make the door turn left or right


Note: After the door pane is installed,if the gap of the door is too large or too small, you can adjust this screw to adjust the gap of the door.

F


ST3.5*14mm
16PCS

ASSEMBLY INSTRUCTION

STEP 20




STEP 21



F
ST3.5*14mm
4PCS
I
4PCS
1PC


ASSEMBLY INSTRUCTION

STEP 22



K
X1
X2
2PCS


STEP 23



K
4PCS


ASSEMBLY INSTRUCTION

STEP 24



K
X1
X2
2PCS

STEP 25



K
2PCS