



Thank you for choosing our screens

All the screens have passed strict quality inspections before delivery. Read this manual carefully to ensure proper usage.


Attention : the installation of the screen is important, the electrical connections, setting of the limit switches, must be conducted by skilled engineers only.

MOTORIZED SCREEN




1.CIRCUIT DIAGRAMS

If the motorized screen work with manual switch, please refer to the diagram below for electric connection.




If the motorized screen work with remote control, please refer to the diagram below for electrical connection.



If the remote control does not work well, please check the battery
And replace new one.

2. ADJUST LIMIT SWITCH

Adjust position for the two limit journey, refer to picture below :



3. USEFUL INSTRUCTIONS

a. The screen should be switched to a suitable power supply, it can be 220V/ 50HZ.230V/ 50HZ or 110V/ 60HZ,120V/ 60HZ, but the motor's power must be same as the local voltage and frequency.

b. The screen can be used with or without the remote controller. The remote control system can be radio type or infrared type. Normally if a remote control system is needed, a radio remote controller is supplied but an infrared type controller is also available for a special requirement. These two different controlling functions cannot be combined in one control system.

c. Normally a synchronized motor is installed inside the housing but a tubular motor is also available for a special requirement.

d. If the remote control system is not accompanied, the screen can be operated by the control box directly. Just push the UP/ DOWN /STOP button on the control box to operate the screen. Alternatively, the screen can be operated by the remote controller.