



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609543P
Power Glider Recliner

ITEM : 609543P

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION




A BACK

B BASE

C LEFT EAR

D RIGHT EAR

E PLUG-IN POWER SUPPLY




ITEM : 609543P


ASSEMBLY INSTRUCTIONS




STEP 1




STEP 2





STEP 3



STEP 4



609543P



Note: Dimension tolerance $\pm 5\%$