

NOTICE

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key


CARE AND MAINTENANCE

- * Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
- * The use of steam or water-based cleaners may cause excessive shrinking or staining.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Left seat		1X
B	Right seat		1X
C	Leg		8X
HW1	Clip		1X
HW2	Clip post		1X
HW3	Screw		6X

Dimensions: 111.8"W X 36.0"D X 28.2"H









Weight Capacity: 550 lbs (each side)

WARNING: DO NOT STAND ON SOFA

WARNING: DO NOT OVER TORQUE BOLTS/SCREWS

PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help.

		
STEP1 OPEN THE ZIPPER ON THE UNDERSIDE OF THE SEAT AND TAKE OUT LEGS AND HARDWARE	STEP2 ROTATE THE LEGS UNTIL TIGHTEN AS SHOWN IN THE PICTURE. CLOSE THE ZIPPER ON THE UNDERSIDE OF THE SEAT.	STEP3 REPEAT THE SAME STEP TO CONTACT THE LEGS FOR THE OTHER SIDE OF SOFA.
		
STEP4 SECURE CLIP TO THE BOTTOM OF SEAT BY USING SCREWS. TIGHTEN ALL SCREWS WITH A PHILLIPSS HEAD SCREWDRIVER (NOT INCLUDED). ALIEN THE CLIP ON THE BOTTOM OF ONE SIDE SOFA TO THE CLIP POSTS ON THE BOTTOM OF THE OTHER SIDE OF SOFA AS SHOWN.	STEP5 PUSH THE BOTH SIDES OF SOFA SLOWLY UNTIL THE CLIP AND THE POST CLICK TOGETHER TIGHTLY.	IF YOU WANT TO UNLOCK THE SOFA. PLEASE LIFT UP THE BODY BY TWO PEOPLE.