
Assembly Instructions

4 DRAWER CHEST



1-14

2017 - 09 - 07

Keep these instructions for future reference

WARNING

Read instructions carefully. Check no parts are missing.

Assemble the furniture on a soft level surface to avoid damaging the furniture or your floor.

Carefully identify each component, especially those that are similar.


The most common mistake is getting things back to front.

Separate and identify each component from the hardware pack and rest each one in it's proper location before fastening.

We recommend furniture be assembled near where they will be placed, to avoid moving the product unnecessarily once assembled.


If there is a need to move the furniture, please remove all loose items and have extra hands to help lift the furniture to the desired location. Dragging the furniture will damage both the furniture and the floor.


Regularly check and re tighten (if necessary) all bolts on furniture that you have assembled yourself



ALLOW 45 MIN


2 Person Required






DO NOT USE ON PRODUCT

Tools Required




2-14 2017 - 09 - 07




CHECKLIST







4-14



































Bx4



12









10-14

2017 - 09 - 07








NOTE:


It is essential that this product is fixed to a wall using the strap supplied.
Wall fixings are not supplied.
Different walls require unique wall fixings.
For advice on suitable wall fixings, contact your local specialized dealer.







Cx16



16

Jx16

