


ASSEMBLY INSTRUCTIONS

CABINET






⚠ WARNING	
	This product is NOT a Clothing Storage Unit (CSU). DO NOT use it for clothing storage. Improper use may cause furniture tipover.

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!
* Please assemble on a clean soft surface to avoid damage.



Tools Required



(Not Included)



(Not Included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Before Installation









Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Cam Lock Assembly Instructions








		Insert Cam Bolt into hole as shown in diagram A.	
		Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.	
		Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.	
			Connect the panels together.
			Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
			To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View - CABINET







Identifying the Hardware - identify the hardware using the illustrations below.














Part List

1	 Top Panel - 1pc	2	 Side Panel Left - 1pc
3	 Side Panel Right - 1pc	4	 Mid Panel - 1pc
5	 Bottom Panel - 1pc	6	 Side Panel Left - 1pc
7	 Side Panel Right - 1pc	8	 Mid Panel - 1pc
9	 Drawer Panel - 1pc		











Part List

10	 Top Panel - 1pc	11	 Mid Panel - 1pc
12	 Back Frame - 1pc	13	 Front Top Bar - 1pc

Part List


14		15	
	Back Panel Top - 1pc		Door Cabinet Top - 2pcs
16		17	
	Door Cabinet Bottom - 2pcs		Mid Bar Rear - 1pc
18		19	
	Front Bottom Bar - 1pc		Back Bottom Bar - 1pc
20		21	
	Drawer Face - 1pc		Drawer Back Panel - 1pc
22		23	
	Drawer Side Panel (L) - 1pc		Drawer Side Panel (R) - 1pc
24		25	
	Bottom Drawer Panel - 1pc		Glass Shelf Panel - 1pc
26			
	Back Panel Bottom - 1pc		

Hardware List



A  $\varnothing 13 \times 1/4" \times 28 \text{mm}$ Hex-Head bolts(16pcs+1)	B  $\varnothing 13 \times 1/4" \times 50 \text{mm}$ Hex-Head bolts(2pcs+1)	C  $\varnothing 1/4" \times 16 \times 1 \text{mm}$ Washer(18pcs+1)
D  $1/4" \times \varnothing 10 \times 13 \text{mm}$ Horizontal-Hole bolts(2pcs+1)	E  $\varnothing 6 \times 35 \text{mm}$ Three in one bolts (27pcs+1)	F  $\varnothing 14.5 \times 12 \text{mm}$ Three in one lock (27pcs+1)
G  $\varnothing 8 \times \varnothing 4 \times 32 \text{mm}$ Round head screw (8pcs+1)	H  Handle (2pcs)	I  Handle (4pcs)
J  $\varnothing 5/32" \times 28 \text{mm}$ Handle screw (8pcs+1)	K  Damping hinge (4pcs)	L  Damping hinge (4pcs)
M  $\varnothing 7 \times \varnothing 3.5 \times 15 \text{mm}$ Flat head screw(48pcs+1)	N  Shelf Pin (4pcs+1)	O  Backplate clips(24pcs+1)
P  $\varnothing 7 \times \varnothing 3.5 \times 15 \text{mm}$ Flat head screw (24pcs+1)	Q  $\varnothing 8 \times 30 \text{mm}$ Wood dowel(44pcs+1)	R  $\varnothing 6 \times 30 \text{mm}$ Wood dowel(4pcs+1)
S  4mm Allen key(1pc)	T  L-Bracket (2pcs)	U  $\varnothing 12 \times 55 \text{mm}$ Plastic stopper (2pcs+1)
V  $\varnothing 10 \times \varnothing 5 \times 50 \text{mm}$ Round head screw (2pcs+1)	W  $\varnothing 10 \times \varnothing 5 \times 20 \text{mm}$ Round head screw (2pcs+1)	X  Power Adaptor(1pc)

STEP: 1

E



8PCS




STEP: 2

F





2PCS


Q




2PCS




STEP: 3



A	C	F	Q
			
4PCS	4PCS	2PCS	6PCS

S

1PC

STEP: 4




A		C		F		Q	
2PCS		2PCS		1PC		4PCS	




S	
	1PC

STEP: 5




STEP: 6

A	C	F	Q
			
4PCS	4PCS	3PCS	10PCS
S			
			
1PC			





STEP: 7

A	C	S
		
2PCS	2PCS	1PC




STEP: 8


O	P
	
24PCS	24PCS




STEP: 9




L	K	M
4PCS	4PCS	16PCS



STEP: 10




I	J	M
4PCS	8PCS	32PCS





STEP: 11

E



19PCS



STEP: 12

F





2PCS

Q




2PCS



STEP: 13

F	Q
	
2PCS	2PCS





STEP: 14


B	D	F	Q
			
1PC	1PC	6PCS	8PCS


S

1PC





STEP: 15




B		D		F	
1PC		1PC		6PCS	
		S		Q	
		1PC		8PCS	

STEP: 16




F		Q	
3PCS		2PCS	

STEP: 17



G	R
	
8PCS	4PCS



STEP: 18





H

2PCS

STEP: 19


X**1PC**

STEP: 20




STEP: 21

A	C	S
		
4PCS	2PCS	1PC




STEP: 22



STEP: 23

N

4PCS




STEP: 24

U




2PCS



STEP: 25

T	V	W
		
2PCS	2PCS	2PCS



STEP: 26

