


ASSEMBLY INSTRUCTION

24 INCH BATH VANITY

SKU: N725P448532





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
* Please assemble on a clean soft surface to avoid damage.




+



Tools Required



(Not included)




(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY


Detail View - VANITY



Identifying the Hardware -Identify the hardware using the illustrations below.


Part List - N725P448532

1




Side Panel (L) - 1pc

2




Side Panel (R) - 1pc

3




Mid Panel - 1pc

4




Bottom Frame - 1pc

5




Top Bar Rear - 1pc

6




Mid Bar Rear- 1pc

7




Bottom Bar Rear - 1pc

8




Top Bar Front - 1pc

9













Top Bar Front - 1pc

10








Cabinet Door - 1pc






Part List - N725P448532

11		12	
Door Side Panel (L) - 1pc		Door Side Panel (R) - 1pc	
13		14	
Round Bar - 2pcs		Door Mid Panel - 2pcs	
15		16	
Mid Drawer Face - 2pcs		Drawer Side Panel (L) - 2pcs	
17		18	
Bottom Side Drawer (R) - 2pcs		Bottom Back Drawer - 2pcs	
19		20	
Bottom Bottom Drawer - 2pcs		Bottom Drawer Face - 1pc	



Part List - N725P448532

21  Drawer Side Panel (L) - 1pc	22  Bottom Side Drawer (R) - 1pc
23  Bottom Back Drawer - 1pc	24  Bottom Bottom Drawer - 1pc
25  Sink - 1pc	


Hardware List- N725P448532

A  ø6x35mm Three in one bolts - 29pcs	B  ø14.5x12mm Three in one lock - 29pcs	C  ø8x30mm Wood dowel - 32pcs
D  ø8xø4x32mm Round head screw - 24pcs	E  ø8xø4x25mm Round head screw - 2pcs	F  Handle - 4pcs
G  ø5/32"x25mm Handle screw - 2pcs	H  ø5/32"x19mm Handle screw - 2pcs	I  Damping hinge - 2pcs
J  ø7xø3.5x15mm Flat head screw -12pcs	K  ø6x30mm Wood dowel - 12pcs	L  Anti fall hardware (2sets)

STEP: 1



STEP: 2




B




2PCS


C




2PCS




STEP: 3




B		C	
3PCS		2PCS	


STEP: 4



E	
2PCS	


STEP: 5

B	C
	
6PCS	5PCS




STEP: 6

B		C	
2PCS		4PCS	





STEP: 7


B	C
	
8PCS	4PCS



STEP: 8





A





8PCS

STEP: 9





J	I	B	C
			
4PCS	2PCS	8PCS	10PCS




STEP: 10


J	G	F
		
8PCS	1PC	1PC




Use the screws to adjust up or down




Use the screws to permanent




Use the screws to adjust left or right




Use the screws to adjust in or out





STEP: 11

K	D	H	F
			
8PCS	16PCS	2PCS	2PCS




STEP: 12



K	D	G	F
			
4PCS	8PCS	1PC	1PC



STEP: 13




STEP: 14




STEP: 15

Install the sink on the cabinet with glue.



Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.



STEP: 16




HINGE ADJUSTMENTS




0 Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



f) 0 Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



E) Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet

